
# SHARP SERVICE MANUAL

S64U3VC-A462G



VHS VIDEO CASSETTE RECORDER

# VC-A462GM (BK) MODELS VC-A462SM (BK)

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

CONTENTS	
1. SPECIFICATIONS	Page 3
2. DISASSEMBLY AND REASSEMBLY	
3. FUNCTION OF MAJOR MECHANICAL PARTS	
4. ADJUSTMENT, REPLACEMENT AND ASSEMBLY OF MECHA	ANICAL UNITS 9
5. ELECTRICAL ADJUSTMENT	36
<ol><li>MECHANISM OPERATION FLOW CHART AND TROUBLESH</li></ol>	
7. TROUBLESHOOTING	
8. BLOCK DIAGRAMS	
9. CIRCUIT DIARAM AND PWB FOIL PATTERN	73
10. REPLACEMENT PARTS LIST	85
11. EXPLODED VIEWS	97
12. PACKING OF THE SET	

### SHARP CORPORATION

### PRECAUTIONS IN PART REPLACEMENT

When servicing the unit with power on, be careful to the section marked white all over.

This is the primary power circuit which is live.

When checking the soldering side in the tape travel mode, make sure first that the tape has been loaded and then turn over the PWB with due care to the primary power circuit.

Make readjustment, if needed after replacement of part, with the mechanism and its PWB in position in the main frame.

(1) Start and end sensors: Q851 and Q852.

Insert the sensor's projection deep into the upper hole of the holder (LHLDZ1893AJ00). Referring to the PWB, fix the sensors tight enough.

(2) Photocoupler RH-FX0005GEZZ: IC901

Refer to the symbol on the PWB and the anode marking of the part.

(3) Cam switches A and B (RH-PX0231GEZZ): D854 and D855.

Adjust the notch of the part to the white marker of the symbol on the PWB. Do not allow any looseness.

(4) Take-up and supply sensors (RH-PX0232GEZZ): D857 and D856.

Be careful not to confuse the setting direction of the parts in reference to the symbols on the PWB. Do not allow any looseness.

(5) Diode bridge (RH-DX0083GEZZ): D901.

Adjust the + marking of the part to the symbol's cathode marking on the PWB.

### 1. SPECIFICATIONS

Format: VHS PAL standard

Video recording system: Two rotary heads, helical scan system

Video signal: PAL/SECAM colour and B/G signals, 625 lines

Recording/playing time: 260min max. with SHARP E -260 tape (SP)

520 min max. with SHARP E-260 tape (LP)

Tape width: 12.7 mm

Tape speed: 23.39 mm/s (SP)

11.70 mm/s (LP)

Antenna: 75 ohm unbalanced

Receiving channel: VHF Channel S1-S41,E2-E12, UHF Channel E21-69

RF converter output signal: UHF Channel E30-39 (preset to E36 Channel)

Power requirement: A230V, 50Hz
Power consumption: Approx. 17W
Operating temperature: 5°C to 40°C
Storage temperature: - 20°C to 60°C

rage temperature: - 20 C to 60 C

Weight: Approx. 3.8kg

Dimensions: 380 mm (W)  $\times$  284.5 mm (D)  $\times$  93 mm (H)

VIDEO

Input: 1.0 Vp-p, 75 ohm Output: 1.0 Vp-p, 75 ohm

**S/N** ratio: 45 dB (SP)

Horizontal resolution: 250 lines

AUDIO 0 dBs = 0.775 Vrms
Input: Line: -3.8 dB, 47k ohm
Output: Line: -3.8 dB, 1k ohm

S/N ratio: 42 dB

Frequency responce: 80 Hz~10 kHz

Accessories included: 75 ohm coaxial cable

Operation manual Infrared remote control

Battery (2pcs.)

As part of our policy of continuous improvement, we reserve the right to alter design and specifications without notice.

Note: The antenna must correspond to the new standard DIN 45325

(IEC 169 - 2) for combined UHF/VHF antenna with 75 ohm connector.

82726 : 7 : 12

### 2. DISASSEMBLY AND REASSEMBLY ...

### 2-1 DISASSEMBLY OF MAJOR BLOCKS

TOP CABINET FRONT PANEL BOTTOM PLATE OPERATION PWB : Remove 4 screws ①. : Remove 7 clips ②. : Remove 1 screw ③.


: Remove 1 screw ④.

Tilt the PWB by 45° and take it out of the socket ⑤.

R/C RECEIVER TUNER HOLDER MECHANISM/ MAIN PWB ASSEMBLY : Take it out of the socket ©.

: Remove 1 screw 🗘 👵 🗸

\*\*Remove 2 screws \*\*B, 2 screws \*\*B, 4 screws \*\*D, 1 screw \*\*D and 1 gromment \*\*D . Lift the rear end of the mechanism/main PWB assembly and take it out of the main frame.



### 2-2 DISASSEMBLING THE MECHANISM/MAIN PWB ASSEMBLY

**CONVERTER** 

: Remove 1 screw (3).

**HOLDER** 

ANTENNA

: Remove 2 screws (4).

TERMINAL COVER

MECHANISM CHASSIS/ : Remove 1 screw (5) and shield

case

CASSETTE HOUSING ASSEMBLY Remove 3 FFCs and 2 harnesses

16.

Be carefull not to confuse the

top and bottom of the FFC.

Remove 1 screw (7).


Remove the mechanism assembly straight up from the main PWB with care not to damage their surrounding

parts.

**CASSETTE** 

**HOUSING** 

: Remove 2 screws (8).




### 2-3 PRECAUTIONS IN REASSEMBLING


### MOUNTING THE CASSETTE CONTROLLER

Initial/setting is indispensable before placing the cassette controller in the mechanism. The initial/setting is made in two ways; electrical and mechanical.

Electrical setting:

Make a short-circuit between TP5001 (or jumper 241) and TP5002 (or jumper 242), both located at the left on your side on the main PWB, with a 22 ohm resistor and be sure that the mechanism is backeto its initial setting position (\*1). Now place the cassette controller in position. (This method is used when the mechanism has been already set on its PWB.)





### Mechanical setting:

AZ MERKEGIS O S S S S S S

#BT#BV##O


Turn the loading motor's pulley feed gear using a screwdriver and be sure that the mechanism is back to its initial setting position (\*1). Now place the cassette controller in position. (This method is applicable for the mechanism alone.)

#### COUPLING THE MECHANISM TO THE PWB


Match the mechanism's projections with the two symbols (round reference and oval sub-reference) on the main PWB. Place the mechanism straight down in position with due care so that the mechanism chassis's outer edges should not damage any parts nearby.

Tighten up the two screws (one for fixing the mechanism and the head amplifier shield, the other on the main PWB's soldering side and located near the loading motor) to fix the mechanism and main PWB. Reconnect the FFC cables (AA, AD and AH) and harnesses (AE and AL) between the mechanism and main PWB.

### Parts to pay attention to:




### 3. FUNCTION OF MAJOR MECHANICAL PARTS (TOP VIEW)



No.	Function		Function
1.	Full erase head ass'y Erase the whole records on the tape in the recording mode.	13.	Reverse guide Pulls out the tape and controls the tape drive train height with the upper and lower guides.
3.	Tension arm ass'y Detects the tension of tape while running, and brakes the supply reel disk via the tension band.	16.	Pinch roller lever ass'y Press-fits the tape to the capstan during tape running. The right protrusion switches the clutch of the cassette
7.	Main supply brake lever Brakes the supply reel disk to prevent tape slackening when the unit is stopped in fast forward or rewind		housing control assembly in "tape eject", and makes the mechanism eject the tape.
	mode.	18.	Loading motor A motive power which drives the mechanism. It
9.	Main take-up brake lever Brakes the take-up reel disk to prevent tape slackening when the unit is stopped in fast forward or rewind mode.		transmits the power to the master cam and cassette housing control assembly.

### FUNCTION OF MAJOR MECHANICAL PARTS (BOTTOM VIEW)



No.	Function	No.	Function
1.	Slow brake lever Gets in contact with the capstan D.D. motor linking to the master cam in the slow still mode, and brakes it to a certain degree.	6.	Reel pulley Transmits the power of the capstan D.D. motor to the reel disk via the reel idler.
3.	Capstan D.D. motor A motive power which runs the tape. It transmits the power via the reel belt.	8.	Shifter Transmits the operation of the master cam to break and loading gear.
<b>4.</b>	Reel belt Transmits the power to run the tape to the reel pulley.	9.	Take-up loading gear Shifts the take-up pole base and guide roller via the loading relay gear, and applies the tape around the drum assembly, as well as transmits the power to the supply loading gear.

### 4. ADJUSTMENT, REPLACEMENT AND ASSEMBLY OF MECHANICAL UNITS

Here we will describe a relatively simple service work in the field, not referring to the more complicated repairs which would require the use of special equipment and tools (drum assembly replacement, for example). We are sure that the easy-to-handle tools listed below would be more than handy for periodical maintenance to keep the machine in its original working condition.

### TOOLS NECESSARY FOR ADJUSTING THE MECHANICAL UNITS

The following tools are required for proper service and satisfactory repair.

No.	Jig Item	Part No.	Code	Configuration	Remarks
1	Reel Disk Height Adjusting Jig	JiGRH0002	BR	9	These Jigs are used for checking and
2	Master Plane Jig	JiGMP0001	BY		adjusting the reel disk height.
3	A/C Head Tilt Adjusting Jig	JiGACH-A323U	вх		This Jig is used for setting the A/C head tilt.
4	Torque Gauge (90g)	JiGTG0090	СМ	9	
	Torque Gauge (1.2 kg)	JiGTG1200	CN		These Jigs are used for checking and adjusting the torque of take-up and
5	Gauge Head	JiGTH <b>00</b> 06	AW		supply reel disks.
6	Cassette Torque Meter	JiGVHT-063	cz		This cassette torque meter is used for checking and adjusting the torque of take-up for measuring tape back tension.
7	Tension Gauge (300g)	JiGSG0300	BF	C II	There are two gauges used for the
,	Tension Gauge (2.0kg)	JiGSG2000	BS		tension measurements, 300 g and 2.0 kg.
	Hex Wrench (0.9mm)	JiGHW0009	AE	a	
8	Hex Wrench (1.2mm)	JiGHW0012	AE		These Jigs are used for loosening or tightening special hexagon type screws.
	Hex Wrench (1.5mm)	JiGHW0015	AE	9	Sciews.
9	Alignment Tape (PAL)	VROCPSV	ск		This tape is especially used for electrical fine adjustment.
11	Tension Gauge Adapter	JiGADP003	вк	S B	This Jig is used with the tension gauge. Rotary transformer clearance adjusting jig.

### VC-A462GM VC-A462SM

No.	Jig-Item	Part No.	Code	Configuration 3	Remarks CARA
12	Special Bladed Screwdriver	JiGDRIVERH-4	ev∜ F <b>AP</b> erfol	The second second second	This screwdriver is used for adjusting, the guide roller height.
14	Torque Driver	JiGTD1200	СВ		This is used to screw down resin- made parts: the specified torque is 5 kg.
	Pov Drivos	JiGDRiVER110-7	AS		This Jig is used for height adjust- ment of the A/C head and X- position.
	14 Box Driver	Jigdriver110-4	ĀV		-This-Jig is used for replacement of the SI roller.
17	Reverse Guide Height Adjusting Jig	JIGRVGH-F18	BU	79 (00.096.) 17 <b>(1.</b> 10.0096.)	This Jig is used for height adjust- ment of the reverse guide.

### MECHANICAL PARTS REQUIRING PERIODICAL INSPECTION

Use the following table as a guide to maintain the mechanical parts in good operating condition.

Maintained Parts	500 hrs.	1000 hrs.	1500 hrs.	2000 hrs.	Possible symptom encountered	Remarks	
Guide roller ass'y	П			0		Abnormal rotation or significant vibration requires replacement.	
Supply impedance roller				0			
Supply impedance roller (inner hole and shaft)					Lateral noises Head occasionally blocked	Clean with pure high quality isopropyl alcohol.	
Supply impedance roller flange					, included the second of the s		
Retaining guide						Clean tape contact part with the specified cleaning liquid.	
Siant pole				0		ilquiu.	
Video head (upper drum ass'y)	□	00		00	Poor S/N ratio, no colour		
Full-erase head				0	Poor colour, beating	]	
A/C head				0	Sound too small or distorted	Clean tape contact area with the specified cleaning liquid.	
Lower drum ass'y				0	Poor flatness of the envelope with alignment tape		
Capstan D.D. Motor		П	п.,	0	No tape running, uneven colour		
Pinch roller				0	No tape running, tape slack	Clean rubber and rubber contact area with the specified cleaning liquid.	
Reel belt	:			0	No tape running, tape slack, no fast forward/rewind motion		
Tension band ass'y			1 100	0	Cassette not loaded or unloaded		
Loading Motor			,	0	Cassette not loaded of diffoaded		
Reel idler ass'y	;			0	No tape running		
Reel pully ass'y				00		·	
Clutch gear ass'y				0			
Main supply/take-up brake levers				0	Tape slack		
AHC (Automatic Head Cleaner)		0		0		Replace the roller of the cleaner when it wears down. Just change the AHC roller assembly for new one.	

	<ul> <li>□: Cleaning (For cleaning, use a lint-free cloth dampened with pure isopropyl alcohol).</li> <li>□: Oil refilling (The indicated point should be lubricated with high quality spindle oil every 1000 hrs).</li> </ul>
If the	reading is out of the specified value, clean or replace the part.

O: Part replacement.

NOTE:

# REMOVAL AND REASSEMBLY OF CASSETTE HOUSING CONTROL ASSEMBLY

### Removal

- 1. Set the cassette ejected condition in the cassette eject mode.
- 2. Unplug the recorder from the main source.
- Follow the procedures below in the specified order.
  - a) Remove the cassette housing installation screws ① and ②.
  - b) Slide and pull out the cassette housing control assembly upward.




Figure 4-1.

### Reassembly

1. Before installation of the cassette housing control assembly, make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Plug in the power cord. The cassette control drive gear starts and stops just when a tally mark appears in the mechanism chassis window. Align this tally mark with the cassette control drive angle's mark, as shown in Fig. 4-2, to position the cassette control on the mechanism chassis.




Figure 4-2.

Follow the procedures for removal in the reverse order.

#### Notes:

- ① In using a magnet screw driver, be sure to keep it away from the A/C head, FE (Full Erase) head, or the drum.
- ② In removal and reassembly, take care not to hit the cassette housing control assembly or tools against the guide pin, drum, or the like thereabout.
- 3 Load the cassette once onto the cassette housing control assembly after reassembly.

# TO RUN A TAPE WITHOUT THE CASSETTE HOUSING CONTROL ASSEMBLY

- Be sure to make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor, before turning on the power.
- 2. Plug in the power cord.
- 3. Turn on the power switch.
- 4. Open the lid of a cassette tape by hand.
- 5. Hold the lid with two pieces of vinyl tape.
- 6. Set the cassette tape in the mechanism chassis.
- 7. Stabilize the cassette tape with a weight (500g) to prevent floating.
- 8. Perform running test.





Figure 4-3.

### Note:

The weight should not be more than 500g.

## REPLACEMENT AND HEIGHT CHECKING AND ADJUSTMENT OF REEL DISKS

- Removal (Supply and Take-up reel disks)
- 1. Remove the cassette housing control assembly.
- 2. Pull the tension band out of the tension arm.
- 3. Remove the supply main brake and the take-up main brake.
- 4. Open the hook at the top of the reel disk, and remove the reel disk.



Supply reel disk

Take-up reel disk




Figure 4-4.

### Note:

When the tension band is pressed in the direction of the arrow for removal, the catch is hard to be deformed.



Figure 4-5.

### • Reassembly (Supply reel disk)

- 1. Clean the reel disk shaft and apply oil to it.
- 2. Install a new supply reel disk onto the shaft.
- 3. Replace the tension band around the supply reel disk, and insert it to the hole of the tension arm.
- 4 Check the reel disk height and reassemble the supply main brake.

### Notes:

- ① Take enough care not to deform the tension band during installation of the supply reel disk.
- Be careful not to damage the supply main brake.

### Reassembly (Take-up reel disk)


- 1. Clean the reel disk shaft and apply oil to it.
- 2. Install a new take-up reel disk onto the shaft.
- 3. Check the reel disk height and reassemble the take-up main brake.

### Note:

Take care not to damage the take-up main brake.

- \* After reassembly, check the video search rewind back tension (see page 16), and check the brake torque (see page 19).
- Height checking and adjustment
   Note:

Place the master plane onto the mechanism unit, taking care not to hit the drum (see Figure 4-6).



Set the master plane releasing the reverse guide by a finger.




Figure 4-6.

### V.C-A462GM VC≎A462SM

 Check that the reel disk is lower than part A but higher than part B. If the height is not correct. readjust the reel disk height by changing the poly-slider washer under the reel disk.

#### Note:

Whenever replacing the reel disk, perform the height checking and adjustment.




Figure 4-7.

### CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN FAST FORWARD MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.

### Setting

- 1. Set a torque gauge to zero on the scale. Place it on the take-up reel disk.
- 2. Press the FF button to set the mechanism to the fast forward mode.

### Checking

- 1. Turn the torque gauge slowly (one rotation every 2 to 3 seconds) by hand in the take-up direction.
- 2. Check to see if the take-up torque is higher than 69 mN·m (700 gf·cm).




Figure 4-8.

### Adjustment

- Section 1919 (Section 1968) 1. If the take-up torque is outside the range, clean the capstan D.D. motor pulley, reel belt and reel pulley with cleaning liquid, then recheck the
- 2. If the take-up torque is still out of range, replace. the reel belt.

### Notes:

- 1. Hold down the torque gauge so that it may not
- 2. When checking the take-up torque, do not keep the reel disk locked for a longer time.

### **CHECKING AND ADJUSTMENT OF TAKE-UP** TORQUE IN REWIND MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB. with a 22 ohm resistor. Now turn on the power.

### Setting

- 1. Set a torque gauge to zero on the scale. Place it on the supply reel disk.
- 2. Press the REW button to set the mechanism to the rewind mode.

### Checking

- 1. Turn the torque gauge slowly (one rotation every 2 to 3 seconds) by hand in the take-up direction.
- 2. Check to see if the take-up torque is higher than 69 mN·m (700 gf·cm).




Figure 4-9.

### Adjustment

- If the take-up torque is outside the range, clean the capstan D.D. motor pulley, reel belt and reel pulley with cleaning liquid, then recheck the torque.
- 2. If the take-up torque is still out of range, replace the reel belt.

#### Notes:

- 1. Hold down the torque gauge so that it may not fly off.
- 2. When checking the take-up torque, do not keep the reel disk locked for a longer time.

# CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN PLAYBACK MODE

- 1. Remove the cassette housing control assembly.
- 2. Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- 3. Open the lid of the cassette torque meter, and hold it with two pieces of vinyl tapes.
- 4. Load the cassette torque meter into the unit.
- Put the weight (500g) on the cassette torque meter.
- 6. Press the REC button to put the unit in REC mode.

Set value SP 8.8 ± 3.8 mN·m (90 ± 39 gf·cm)




Figure 4-10.

### Checking

- 1. Check that the torque is in the range of 8.8 ± 3.8mN·m (90 ± 39gf·cm).
- 2. The torque fluctuates due to the rotational deviation of the reel pulley ass'y. Use the center of the fluctuation as the value.
- 3. Place the ass'y in the SP record mode, and check that the take-up torque is within the range.

### Adjustment

If the take-up torque in the playback mode is outside the range, replace the reel pulley ass'y.

### Note:

Stabilize the cassette torque meter to prevent floating.

# CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN VIDEO SEARCH REWIND MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.

### Setting

- 1. Push the PLAY button to place the ass'y in the playback mode.
- 2. Push the REW button to place the ass'y in the video search rewind mode.

### Checking

1. Place the torque gauge on the supply reel disk, and turn it counterclockwise very slowly (one rotation every 1 to 2 seconds) and check that the torque is within the set value 14.5 <sup>+80</sup>/<sub>-6</sub> mN·m (148 <sup>+80</sup>/<sub>-6</sub> gf·cm)




Figure 4-11.

#### Note:

Set the torque gauge securely on the supply reel disk. If it is not secure, the measurement will be incorrect.

### Adjustment


If the take-up torque in video search rewind mode is outside the range, replace the reel pulley ass'y.

#### Note:

The torque fluctuates due to the rotational deviation of the reel pulley ass'y. Use the center of the fluctuation at the value.

# CHECKING THE FAST FORWARD BACK TENSION

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- Checking
  - 1. Push the FF button to place the ass'y in the fast forward mode.
  - Place the torque gauge on the supply reel disk, and turn it clockwise very slowly (one rotation every 2 to 3 seconds) and check that the torque is 1.5 ± 0.9mN·m (15 ± 9gf·cm).



Note:

- Figure 4-12.
- Set the torque gauge securely on the supply reel disk. If the torque gauge is not securely set on the reel disk, measurement will be incorrect.
- ② Measure the torque with the torque gauge's weight exerted on the reel disk.

### **CHECKING THE REWIND BACK TENSION**

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- Checking
  - 1. Push the REW buton to place Place the ass'y in the rewind mode.
  - 2. Place the torque gauge on the take-up reel disk, and turn it counterclockwise very slowly (one rotation every 2 to 3 seconds) and check that the torque is 1.3 ± 0.8 mN·m (13 ± 8gf·cm).




Figure 4-13.

#### Note:

- Set the torque gauge securely on the take-up isseed disk. If it is not secure, the measurement will be incorrect.
- ② Measure the torque with the torque gauge's weight exerted on the reel disk.

### CHECKING THE VIDEO SEARCH REWIND BACK TENSION

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.

### Checking

- 1. Push the PLAY button to place the ass'y in the playback mode.
- 2. Push the rewind button to place the ass'y in the video search rewind mode.
- Place the torque gauge on the take-up reel disk, and turn it counterclockwise very slowly (one rotation every 2 to 3 seconds) and check that the torque is within the set value 4±1.7mN·m (41±17gf·cm).




Figure 4-14.

### Note:

- ① Set the torque gauge securely on the take-up reel disk. If it is not secure, the measurement will be incorrect.
- ② Measure the torque with the torque gauge's weight not exerted on the reel disk.

### **CHECKING THE PINCH ROLLER PRESSURE**

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.

### Checking

Push the PLAY button to place the ass'y in the playback mode.




Figure 4-15.

- 1. Detach the pinch roller from the capstan shaft.
- 2. Set the tension gauge by hooking the tension gauge adapter onto the pinch roller shaft.
- 3. Gradually release the pressure to allow the pinch roller to touch the capstan shaft. When the pinch roller just touches the capstan shaft, read the indication on the gauge.
- Check that the reading of the tension gauge is in the range of 900 to 1200 g.

## CHECKING AND ADJUSTMENT OF TENSION POLE POSITION

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- Setting
- 1. Open the lid of cassette tape (E-180), and hold it with two pieces of vinyl tapes.
- 2. Load the cassette tape into the unit.
- 3. Put the weight (500g) on the cassette tape.




Figure 4-16.

- Checking
- Set a cassette tape, press the REC button and get the tape loaded. Now check the tension pole position.

2. Visually check to see if the left end of the tension pole is in alignment with the line 0.2 mm left of the center line of the SI roller. Readjust as required in the following steps.




Figure 4-17.

① If the end is at the left from the dotted line:




Figure 4-18.

- Remove the cassette and press the REC button to make an empty loading. Put a bladed screwdriver into the tension band positioning cam and turn it clockwise.
- 2. Place the cassette in position and check the tension pole position.
- ② If the end is at the right from the dotted line:




Figure 4-19.

- Remove the cassette and press the REC button to make an empty loading. Put a bladed screwdriver into the tension band positioning cam to turn it counterclockwise.
- 2. Place the cassette in position and check the tension pole position.



Note:

The tension band positioning cam cannot be adjusted with a cassette in place because the cam will be located below the cassette. Repeat a series of steps; empty loading, adjustment, cassette placement and position checking.

ina werd yiranin

② Turn the positioning cam clockwise to move the tension pole to the right (in the black-arrow direction). Turn it counterclockwise to move the tension pole to the left (in the white-arrow direction).




Figure 4-20.

3 Adjustable range of the tension pole positioning cam.




Figure 4-21.

Adjust the tension pole positioning cam so that the arrow mark on the cam be within 90° left and right from the tension arm shaft's center.

# CHECKING AND ADJUSTMENT OF RECORD / PLAYBACK BACK TENSION

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- Setting
- 1. Open the lid of the cassette torque meter, and hold it with two pieces of vinyl tapes.
- 2. Load the cassette torque meter into the unit.
- 3. Put the weight (500g) on the cassette torque meter.




Figure 4-22.

### Checking

- 1. Push the REC button to place the unit in the record mode.
- 2. Check that the back tension indicated by the gauge is within the set range 31 to 38 g-cm.

### Notes:

- 1. Make sure that the video cassette tape is over the retaining guide.
- 2. Make sure that the tape is not slack nor damaged at either end.

### Adjustment

- 1. If the reading of the cassette torque meter is less than specified, move the tension spring hook toward A.
- 2. If the reading of the cassette torque meter is more than specified, move the tension spring hook toward B.





Figure 4-23.

### **CHECKING THE BRAKE TORQUE**

Checking the brake torque at the supply side



CCW: 10 ± 4mN·m (102 ± 41gf·cm) CW: 35 ± 20mN·m (357 ± 204gf·cm)


Figure 4-24.

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- Setting
- 1. Set a torque gauge to zero on the scale. Place it on the supply reel disk.
- 2. Switch from the FF mode to the STOP mode.
- 3. Disconnect the AC power plug.

### Checking

1. Slowly rotate the torque gauge in the clockwise (CW) direction and counterclockwise (CCW) direction of the supply brake so that the reel disk and the indicator of the torque gauge rotate at an equal rate. Check that the values are within the range of CW direction = 35 ± 20mN·m (357 ± 204gf·cm), CCW direction = 10 ± 4mN·m (102 ± 41gf·cm), and that the brake torque in the CW direction is at least twice as high as that in the CCW direction.

Checking the brake torque at the take-up side



CCW: 35 ± 20mN·m (357 ± 204gf·cm) CW: 10 ± 4mN·m (102 ± 41gf·cm)

Figure 4-25.

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.

### Setting

- 1. Set a torque gauge to zero on the scale. Place it on the take-up reel disk.
- 2. Switch from the FF mode to the STOP mode.
- 3. Disconnect the AC power plug.

### Checking

- Slowly rotate the torque gauge in the clockwise (CW) direction and counterclockwise (CCW) direction of the take-up brake so that the reel disk and the indicator of the torque gauge rotate at an equal rate. Check that the values are within the range of CCW direction = 35 ± 20mN·m (357 ± 204gf·cm), CW direction = 10 ± 4mN·m (102 ± 41gf·cm), and that the brake torque in the CCW direction is at least twice as high as that in the CW direction.
- Adjustment of the brake torque at the supply side and the take-up side
- 1. If the supply or take-up brake torque is outside the range, clean the supply or take-up reel disk break lever pad, then recheck the torque.
- If the supply or take-up brake torque is still outside the range, replace the main brake ass'y or the main brake spring.

### Note:

When the main brake is replaced, perform the height checking and adjustment of reel disks (see page 13), and the brake torque checking.

## REPLACEMENT OF A/C (Audio/Control) HEAD

- 1. Remove the cassette housing control assembly.
- 2. Place the unit in the unloading mode, and unplug the power cord.

### Removal

- 1. Loosen the tilt adjusting screw ①.
- 2. Remove the azimuth adjusting screw ②.
- 3. Remove the A/C head screw 3.
- Unsolder the A/C head PWB soldered to the A/C head assembly.

### Notes:

- After replacement, be sure to perform the adjustment of the tape drive train (see page 22).
   Under any circumstances, avoid touching the head. Clean the head, if touched with your finger, with alcohol.
- 2. Take care that the azimuth spring does not fly off when removing the A/C head screw.




Figure 4-26.

### Replacement

- Solder the removed A/C head PWB onto a new A/C head assembly.
- 2. The A/C head assembly is attached so that the A/C head arm and A/C head plate are roughly parallel to each other.




Figure 4-27.






Figure 4-28.

### Adjustment

### [A/C head tilt angle]

- 1. Set the mechanism to the loading mode.
- 2. Place the A/C head tilt adjusting Jig ①.
- 3. Slowly turn the tilt adjusting screw ② with a screw driver until there is no gap between the Jig and the A/C head.





(a)


(b) Figure 4-29.

### [A/C head height rough adjustment]

### **HEIGHT ADJUSTMENT OF REVERSE GUIDE**

### Setting

### [Height adjustment of reverse guide]



Box driver





Figure 4-31.

- ① Roughly adjust the height of the A/C head by turning the A/C head adjusting hexagon nut with the specialized box driver until the tape is in the position shown below.
- ② Set the cassette tape to the mechanism chassis.
- ③ Press the PLAY button to the put the unit in the playback mode.

### Adjustment



Adjust the nut visually so that the control head is visible 0.3 to 0.5mm below the bottom of the tape.

Figure 4-30.

- 1. In the tape load mode, make adjustment at the 13.38mm side first and then rotate the height adjusting nut by 1/6 turn counterclockwise.
- Actually load the unit with a tape, put it in the play mode, and make sure the tape is free from wrinkles near the reverse guide.
- 3. Use a commercially available box driver to turn the height adjusting nut.

Burgara Baranasa





Figure 4-32.


### ADJUSTMENT OF TAPE DRIVE TRAIN

- 1. Remove the cassette housing control assembly.
- 2. Make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor. Now turn on the power.
- 3. Check and adjust the position of the tension pole. (See page 17.)
- 4. Check and adjust the video search rewind back tension. (See page 16.)
- 5. Set the tilt angle of the A/C head. (See page 20.)
  - 6. Rough adjustment of tape drive train.
    - a) Connect the oscilloscope to the test point for PB CHROMA envelope output (TP2201). Set the synchronism of the oscilloscope to EXT. The PB CHROMA signal is to be triggered by the head switching pulse (TP2202).
  - b) Loosen the setscrew at the lower part of the setscrew driver (JIGDRIVERH-4) so that the guide roller turns smoothly: (Do not overloosen the setscrew, which causes insecurity of the guide roller.) (See Figure 4-33.)
    - c) Set the alignment tape (monoscope pattern) on the reel disk, and place the unit in the playback mode.

(Place a 500 g weight on the cassette tape to prevent floating of the cassette tape.)



- d) In the X value adjustment mode (see the Electrical Adjustment), change the envelope waveform from MAX to MIN, and MIN to MAX by pushing the (+) or (-) tracking button, and check a flat response is obtained on the waveform.
- e) If a flat response cannot be obtained, roughly adjust the guide rollers on the supply side and take-up side using an adjusting screw driver until a flat response can be obtained.
- f) Turn the A/C head tilt adjusting screw with a screwdriver to prevent the tape from wrinkling at the upper and lower flanges of the fixed guide.
  - 1) Wrinkles at the upper flange: Turn the above adjusting screw clockwise, as shown in Figure 4-35 (a).
  - 2) Wrinkles at the lower flange: Turn the above adjusting screw counterclockwise, as shown in Figure 4-35 (b).



(b) Figure 4-35.

### Notes:

- A. Place the tracking control in the center position, and adjust the X-position adjusting nut so that the PB CHROMA envelop becomes maximum for easier rough adjustment of the tape drive train.
- 2. In the rough adjustment, pay particular attention to the outlet side.




Figure 4-36.

Figure 4-37.




Figure 4-38.

- 7. Adjustment of A/C head height and azimuth
  - a) Connect an oscilloscope to the audio output terminal.
  - b) Use the alignment tape and play back its audio 6 kHz signal (monoscope pattern for video signal). Adjust the azimuth adjusting screw to obtain the maximum audio output on an oscilloscope. (See Figure 4-39.)
  - c) Use the alignment tape and play back its audio 1 kHz signal (colour bar for video signal) and slowly rotate the A/C head height adjusting nut with the special box driver to obtain the maximum audio output.
  - d) Perform the adjustment in b) again.
  - e) After this adjustment, apply glyptal to the screws and nuts to fix them.




Figure 4-39.

Figure 4-40.


- 8. Adjustment of tape drive train and X-Position.
  - a) Connect the oscilloscope to the test points (TP2201) for PB CHROMA envelope output. Set the synchronism of the oscilloscope to EXT. The PB CHROMA signal is to be triggered by the head switching pulse (TP2202).
- b) Play back the tape drive train alignment tape.
- c) Push the (+) or (-) button to change the envelope waveform from MAX to MIN, and MIN to MAX. Adjust the guide roller's height on the supply and take-up sides with an adjusting screw driver, to obtain an envelop waveform that is as flat as possible.
- d) If the tape is above or below the helical lead, the PB CHROMA waveform will take the shape shown in Figure 4-41.
- e) Adjust for maximum flatness of the envelope as the step 6, e) in page 22.

	When the tape is abo	ove the helical lead.	When the tape is below the helical lead.		
	Supply side	Take-up side	Supply side	Take-up side	
Adjustment	Supply side guide roller rotated in clockwise direction (lowers guide roller) to flatten envelope.	Take-up side guide roller rotated in clockwise direction (lowers guide roller) to flatten envelope.	Supply side guide roller rotated in counterclockwise direction (raises guide roller) to make the tape float above the helical lead. The supply side guide roller is then rotated in the clockwise direction to flatten the envelope.	Take-up side guide roller rotated in counterclockwise direction (raises guide roller) to make the tape float above the helical lead. The take-up side guide roller is then rotated in the clockwise direction to flatten the envelope.	

Figure 4-41.

### VC-A462GM VC-A462SM

- f) Push the (+) or (-) tracking button to check that a flat response is obtained on the envelope waveform.
- g) Secure the guide roller by tightening the guide roller setscrew in the unloading mode.
- h) Play back the tape drive train alignment tape to check that the envelope waveform does not change.
- 9. Adjustment of A/C head X-position.
  - a) In the X value adjustment mode (see the Electrical Adjustment), make a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor, to center the tracking.
  - b) Rotate the X-position adjusting nut with an adjusting box driver, and adjust the A/C head position for maximum head switching pulse low side envelope.
  - c) Adjust the playback switching point.
  - d) Check the flatness of the envelope waveform and sound by playing back a recorded tape.



# REPLACEMENT OF THE CAPSTAN D.D. (DIRECT DRIVE) MOTOR

- Remove the cassette housing control assembly.
- Removal (Follow the order of indicated numbers.)
- Disconnect from the board-to-board connector on the main PWB.
- 2. Remove the reel belt ①.
- 3. Remove the screws ②.




Figure 4-43.

### Reassembly

- 1. Mount the capstan motor on the mechanism chassis making sure not to allow the capstan shaft to hit the mechanism chassis, and attach it with the three screws.
- 2. Attach the reel belt. Reconnect to the board-to board connector on the main PWB.

#### Notes:

- 1. After installing the capstan D.D. motor, be sure to rotate the capstan D.D. motor and check the movement.
- 2. Check the servo circuit.

### **REPLACEMENT OF DRUM D.D. MOTOR**

- 1. Put the unit in the cassette eject position.
- 2. Unplug the power cord.
- Removal (Reverse the order in reassembly.)
- 1. Disconnect the FFC cable ①.
- 2. Unscrew the stator assembly fixing screws ②.
- 3. Take out the stator assembly 3.
- 4. Unscrew the rotor assembly fixing screws 4.
- 5. Take out the rotor assembly ⑤.

#### Notes:

- In removing the stator assembly, part of the drum earth spring pops out of the pre-load collar.
  - Be careful not to lose it.
- Secure the rotor assembly so that the installation positioning holes in the rotor assembly and upper drum assembly match.
  - (Match the upper drum's notch with the rotor's hole.)
- 3. Be careful not to damage the upper drum or the video head.
- 4. Be sure that the hall device and the stator assembly are not damaged by the rotor assembly or other parts.
- 5. After installation, adjust the playback switching point.




Figure 4-44.

# REPLACEMENT OF UPPER DRUM (2-head/4-head drum models are applicable here. Hi-Fi models are equipped with an upper-and-lower drum assembly.) Note:

The gap between the lower drum and the upper drum is very accurate, in the order of microns, and care should be paid to their replacement. Even a slight amount of foreign material will affect the accuracy of their reassembly.

### Replacement (Follow the order of the indicated numbers.)

- ① Remove the drum earth brush and its spring ①.
- ② Put a mark for the direction of the pre-load collar and the drum shaft ②.
- ③ Loosen the set screws (M4) ③ of the pre-load collar. Take out the pre-load collar upward.
- Pull up the upper drum out of position.

   Note:
- 1. Remove the drum motor, referring to the drum motor replacement.
- Put a mark, with a marking pen or the like, in order to identify the direction of the pre-load collar and the drum shaft. Now remove the preload collar.
- 3. Be careful not to lose the drum earth brush and drum earth brush spring.

  Handle the brush with care not to allow any dust and foreign matters on it.
- 4. Avoid touching the drum surface with bare hands.
- 5. Pull out the upper drum with care so that it may not be tilted.
- 6. Do not hit the screws when tightening them.




Figure 4-45.

### VC-A462GM VC-A462SM

- Drum replacement (for 2/4 drums; drum assembly supplied for Hi-Fi models)
- 1. Clean up the drum shaft.
- 2. Make a clearance at the rotary transformer. This is an important procedure to maintain the performance.
  - 1) Some rotary transformer clearance shims are packaged in the servicing upper drum assembly or lower drum assembly. Install the thinnest (0.06 mm) of the shims onto the lower drum shaft. (Refer to Fig. 4-46(a) for thickness.)
  - Install the upper drum assembly onto the drum shaft.
  - 3) Install the pre-load collar.
  - 4) Exert a force of 14.7 N (1.5 kgf) on the preload collar from above (using a commercially available load meter). Tighten up the set screws (M4) of the pre-load collar.
  - Turn the upper drum by hand and listen to see if the rotary transformer gives no rubbing sound.
  - 6) If the transformer sounds, replace the installed shim with the next thicker shim.
    Take the above steps 1) thru 5) until no rubbing sound is heard any longer.
  - 7) Make sure no rubbing sound is heard. Finally add the 0.03 mm thick shim.
- 3. Place the pre-load collar back in position in the direction marked in disassembling. (See Fig. 4-45. for setting.)
- Exert a force of 14.7 N (1.5 kgf) upon the preload collar from above. Tighten up the set screws of the pre-load collar (1.18 Nm (12 kgf-cm)).
- 5. Place the drum earth brush, drum earth brush spring and drum motor back in position.
- After replacement, be sure to check the tape drive train adjustment (See page 22.) and the following electric adjustments.
  - Adjustment of the playback switching point.
  - Checking and adjustment of the X-position.
  - Adjustment of SP slow tracking preset.

### • Precautions in drum replacement

- 1. The drum assembly is very delicate. Handle it with enough care.
- 2. Be certain that the drum surface is free from dust, dirt and any other foreign matters.
- 3. Carefully adjust the rotary transformer clearance because this adjustment is important in order to maintain the performance.
- 4. Install the upper drum straight down to the drum shaft. Do not apply any excessive force upon the upper drum.
- Finally clean up the drum.

Section of the sectio

No	Thickness (mm)	Shape	No	Thickness (mm)	Shape
1	t = 0.060		5	t = 0.100	38°
2	t = 0.070		6	t = 0.110	No.
3	t = 0.080	300	7	t = 0.120	
4	t = 0.090	\$50	8	t = 0.030	

Figure 4-46(a).

### Shim thickness variations

### Pressure collar set-up direction




Figure 4-46(b).

### ASSEMBLE THE MECHANISM'S PARTS RE-QUIRING THE PHASE MATCHING IN THE STEPS BELOW.

- 1. Assembling the pinch roller assembly and the pinch drive cam (on the front of the mechanism chassis).
- 2. Mounting the shifter (on the back of the mechanism chassis).
- 3. Mounting the master cam (on the back of the mechanism chassis).
- 4. Mounting the connection gear, slow brake and loading motor assemblies (on the back of the mechanism chassis).
- 1. Assembling the pinch roller assembly and the pinch drive cam (on the front of the mechanism chassis).

Place the following parts in position in numerical order.

- (1) Pinch drive cam ①
- (2) Pinch roller and pinch double-action lever @
- (3) Open lever 3




Figure 4-47.






Figure 4-48-1.

Pinch Drive Lever



# 2. Mounting the shifter (on the back of the mechanism chassis).



- 1. Make sure that the loading gear is at the point (1) as shown below.
- 2. Place the shifter in position, keeping in mind the 7 insertion points and the five relief points.
- 3. For the phase matching at the insertion point (1), see the point (2) as shown below.
- 4. Finally fix the shifter with two washers located on insert points ① and ⑥.




Figure 4-50.


# 3. Mounting the master cam (on the back of the mechanism chassis).

- (1) Make sure beforehand that the shifter is at the point as shown below.
- (2) Place the master cam in the position as shown below.

### Note:

See the figure below for the phase matching between the master cam and the cassette control drive gear.

(3) Finally fix the master cam with E ring.




- 4. Mounting the connection gear, slow --- cbgake and loading motor assemblies (on ion the back of the mechanism chassis):
- (1) Assemble the connect gear.
- (2) Assemble the slow brake.
- (3) Assemble the loading motor unit.

Note:

of the model (1) Make state

Let the slow brake leg out of the front of the mechanism chassis. Catch the spring to the take-up

fixing guide that is at the left of the A/C head.



### Note:

Before setting up the loading motor, make sure the phase is matched. To do so, turn the connection gear clockwise and check to see if the loading is complete and if the pinch roller comes into contact.

When these actions are made smoothly, return the mechanism to the state as shown above. Finally mount the loading motor unit.

### REPLACEMENT OF LOADING MOTOR

### Removal

Remove 2 screws.




Figure 4-53.

### • Replacement

① Take out the old loading motor. Place a replacement loading motor as shown above (figure 4-53.).




Figure 4-54.

② Adjust the worm gear's thrust gap to 0.05 to 0.3 mm.

Use the specific washers for an appropriate thickness.





Figure 4-55.

Press-fit the loading motor pulley with a force of less than 98N (10 kgf). Be sure that the pulley is  $11.5\pm0.05$  mm away from the motor.

\* Removal

Remove 2 schedus



### **Phase Matching Point**

• Fix the drive angle ass'y to the drive gear R as shown in the figure.




Figure 4-56.

### ② Synchro Gear, Drive Gear L and Drive Gear R




Figure 4-57.

Align the drive gear's round hole with the synchrogear's triangular ( $\triangle$ ) symbol. Do this alignment for both the drive gears.

### **Phase Matching Point**




Figure 4-58.

### Note:

Do not over-turn both of the drive gears when the phase has been matched. These gears are partially toothless and might come out of mesh with the synchro gear. In such a case, the phase needs rematching.

### 5. ELECTRICAL ADJUSTMENT

#### Notes:

### • Before the adjustment:

Electrical adjustments discussed here are often required after replacement of electronic components and mechanical parts such as video heads.

Check that the mechanism and all electric components are in good working condition prior to the adjustments, otherwise adjustments can not be completed.

### Instruments required:

- **©Colour TV** monitor
- @Audio signal generator
- **ODC** voltmeter
- Blank video cassette tape
- **Screwdriver** for adjustment
- ©Colour bar signal generator

- ODual-trace oscilloscope
- OAC milli-voltmeter
- ©Frequency counter
- **OAlignment tape (VROCPSV)**

មិន សិស្សិយៈស្រាល់ 4 កាស់ នេះ ប្រកាស្ត្រស្និត្

### **X Servicing precautions**

When the IC804 (E<sup>2</sup>PROM) has been replaced, make the following reprogramming. Depending on models, the IC804 (E<sup>2</sup>PROM) has been factry-adjusted for it's memory function. It's therefore necessary to reprogram the memory function for the model in question. Note that the servo circuit requires readjustments for the head switching point, slow and still modes.

### Location of controls and test points




Figure 5-1.

### SERVO CIRCUIT ADJUSTMENT

### ADJUSTMENT OF HEAD SWITCHING POINT

Measuring instrument	Dual-trace oscilloscope Colour TV monitor
Mode	Playback
Cassette	Alignment tape (VROCPSV)
Test point	TP2202 (H. SW. P.) to CH-1 VIDEO OUT jack to CH-2 (CH-1 trigger slope switch at (+), Internal trigger at CH-1 side.)
Specification	6.5 ± 0.5H (lines)

- Remove the front panel and play the alignment tape. (VROCPSV)
   (Playback picture on the monitor screen.)
- Make for a moment short-circuit between jumper pins 33 and 34 both located at the left on your side on the main PWB.
   Be sure that all the fluorescent display tubes
- light up into the TEST mode. (See Note below)

  3. Press the PLAY button.

  Pagure the "PLAY" appears in the fluorescent

Be sure the "PLAY" appears in the fluorescent display tubes flashing (about 1Hz) into the auto PG adjustment operating.

### Note:

When the manual PG adjustment, observe the waveform with an oscilloscope and make adjustment FF or REW button so that the specification.

- 4. Stop the "PLAY" appears in the flashing of fluorescent display tubes at adjusted.
- 5. Press the STOP button in the return to normal mode.
- Make this checking of waveform on the oscilloscope screen be as shown in Figure 5-2. just after the head switching point have been adjusted.

### Notes:

- ① Set-up of TEST mode.

  When the adjustment of HEAD SWITCHING POINT, AUTO TRACKING function is invalid.
- ② When the cassette housing control ass'y is removed, set-up of mechanism operating mode.
- 1) Replug the AC power cord a few minute later.
- 2) Making a short-circuit between TP5001 (or jumper pin 241) and TP5002 (or jumper pin 242), both located at the left on your side on the main PWB, with a 22 ohm resistor to center the tracking.
- 3) AC power cord is plugged in.
- 4) You can make mechanism operating mode. Replug the AC power cord a few minute later.




Figure 5-2.

## ADJUSTMENT OF SP/LP SLOW TRACKING PRESET

Measuring instrument	Colour TV monitor
Mode	Playback
Cassette	Self-recorded tape (SP/LP mode) (See Note below)
Control	Tracking control buttons (+) or (-)
Specification	Minimized noise on monitor screen

- 1. Have the unit to receive a good TV broadcast or feed a video signal to the VIDEO IN jack. (See note @ below)
- 2. Set the tape speed in SP mode by using the remote control and record the signal on tape.
- 3. Rewind and play the tape where signal was recorded in above step.
- Press the SLOW button on the remote control, and playback the recorded portion in the slow mode.
- 5. Make for a moment short-circuit between jumper pins 33 and 34 both located at the left on your side on the main PWB.
  - Be sure that all the fluorescent display tubes light up into the TEST mode.
- 6. Look at the monitor screen and adjust the (+) or (-) TRACKING buttons so that the there is noise disappears from the screen.
- 7. Press the STOP button to return to normal mode.
- 8. Play the tape a few seconds then press the SLOW button again and make sure there is no noise in the screen.
  - (For the LP mode put adjustment at the same adjustment way as SP mode.)

### Notes:

- ① Self-recorded tape means a cassette whose program was recorded by the unit being adjusted.
- ② The TV program will not be recorded if RCA or 21pin plugs are pluged in to the AUDIO/VIDEO input terminals.

# ADJUSTMENT OF FV (False Vertical Sync) OF STILL PICTURE ...

Measuring instrument	Colour TV monitor
Mode	Playback still
Cassette	Self-recorded tape (SP mode) (See Note below ②)
Control	Tracking control buttons (+) or (-)
Specification	No vertical jitter of picture

- 1. Play a cassette which was recorded by the unit in SP mode.
- 2. Press the PAUSE/STILL button to freeze the picture.
- 3. Look at the monitor screen and adjust (+) or (-) TRACKING buttons so that the vertical jitter of the picture to be minimized.
- Play and freeze the self-recorded tape in SP mode and make sure vertical jitter of the picture is not noticeable.
  - (For the LP mode put adjustment at the same adjustment way as SP mode.)

### Note:

- ① The FV goes back to the it's initial state when the unit is put into the system controller reset mode due to power failure, etc.
  - In this case, preset the FV once again.
- ② Self-recorded tape is a cassette whose program was recorded by the unit being adjusted.

THE TABLE 1999 TO A STATE OF THE PROPERTY OF T


and the territor are in discounting and

### Y/C CIRCUIT ADJUSTMENT

### **CHECKING OF VIDEO E-E LEVEL**

Measuring instrument	Oscilloscope
Mode	E-E or Record
Input signal	EIA colour bar (1.0Vp-p)
Test point	VIDEO OUT jack
Specification	1.0 ± 0.1Vp-p

- Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor. (See Note below.)
- 2. Feed a colour bar signal to the VIDEO IN jack.
- 3. Make sure that the E-E signal amplitude is 1.0 Vp-p as shown in Figure 5-3.



### Note:

If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.

### CHECKING OF WHITE CLIP LEVEL

Measuring instrument	Oscilloscope
Mode	E-E or Record
Input signal	EIA colour bar (1.0Vp-p)
Test point	Pin (48) of IC401, GND
Specification	190 ± 5% (See note below)

- 1. Connect a oscilloscope to Pin (48) of IC401 and GND.
- Feed the colour bar signal to the VIDEO IN jack and set the unit in E-E or recording mode.
- 3. Make sure that the overshoot of the video signal is clipped at 190% as shown in Figure 5-4.




Figure 5-4.

### Note:

From sync tip to white peak, the level is 100%. The white clip level is 90% above the white level.

### **CHECKING OF RECORD LEVEL**

Measuring instrument	Oscilloscope
Mode	Record mode
Input signal	ElA colour bar (1.0Vp-p)
Test point	Pin (26) of IC301, GND.
Specifications	4head models (SP mode) Chroma (Red) : 47 ± 4mVp-p Sync tip : 200 ± 30mVp-p
	4head models (LP mode) Chroma (Red) : 34 ± 3mVp-p Sync tip : 170 ± 20mVp-p

- 1. Feed the colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 2. Connect an oscilloscope to shown in table.
- 3. Make a short circuit between pin (52) of IC401 and the GND using a 47μF/16V capacitor to minimize the FM luminance signal.
- 4. Make sure so that the amplitude of the chroma (red) portion is specified as shown in Figure 5-5(a).
- 5. Disconnect the capacitor that was connected in step 3.
- 6. Make sure so that the amplitude of the sync tip portion is specificed as shown in Figure 5-5(b).




Figure 5-5(a).

Figure 5-5(b).

### CHECKING OF PLAYBACK LEVEL

Measuring instrument	Oscilloscope
Mode	Record/Playback
Input signal	EIA colour bar (1.0Vp-p)
Test point	VIDEO OUT jack
Specification	1.0 ± 0.1Vp-p

- 1. Be sure that E-E level has been correctly specificed.
- Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor.
   (See Note below.)
- 3. Feed a colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 4. Play the colour bar portion of the recorded tape.
- 5: Make sure that the output signal amplitude is 1.0Vp-p as shown in Figure 5-6.

### Note:

If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.




Figure 5-6.

assas illighii ovy

on the contract to the first term of the first

fit is share eve best

### **AUDIO CIRCUIT**

### CHECKING OF E-E LEVEL

Measuring instrument	AC milli-voltmeter
Mode	E-E/Record
Input signal	1kHz, -8.0dB (at RCA type jack) 1kHz, -3.8dB (at 21 pin type jack)
Test point	AUDIO OUT jack
Specification	- 8.0 ± 2dB (at RCA type jack) - 3.8 ± 2dB (at 21 pin type jack)

- 1. Connect an oscilloscope to the AUDIO OUT jack.
- 2. Feed the audio signal shown in table to the AUDIO IN jack.
- 3. Put the unit in E-E or recording mode.
- 4. Make sure that the output level is value shown in table.

### **CHECKING OF AUDIO PLAYBACK LEVEL**

Measuring instrument	AC milli-voltmeter.
Mode	Playback
Input signal	Alignment tape. (VROCPSV) (1kHz level conrtol signal)
Test point	AUDIO OUT jack
Specification	- 9 <sup>+ 2dB</sup> - 1dB

- Playback the Alignment tape. (VROCPSV 1kHz level audio signal)
- Connect an AC milli-voltmeter to the AUDIO OUT jack.
- 3. Make sure that the output level is value shown in table.

### **CHECKING OF AUDIO RECORD LEVEL**

Measuring instrument	AC milli-voltmeter
Mode	Record/playback
Input signal	1kHz, – 8.0dB (at RCA type jack) 1kHz, – 3.8dB (at 21 pin type jack)
Test point	AUDIO OUT jack
Specification	- 8.0 ± 3dB (at RCA type jack) - 3.8 ± 3dB (at 21 pin type jack)

- 1. Connect an oscilloscope to the AUDIO OUT jack.
- 2. Feed the audio signal shown in table to the AUDIO IN jack.
- 3. Make the self-recording and playback of the signal.
- 4. Make sure that the output level is value shown in table.

If it is out of specified value, verify the bias current (ADJUSTMENT OF AUDIO BIAS CURRENT below).

### ADJUSTMENT OF AUDIO BIAS CURRENT

Measuring instrument	AC milli-voltmeter
Mode	Record
Input signal	Not required
Test point	TP601 (+)~TP602 (-)
Control	R634 Bias current control
Specification	2.5 ± 0.1 mVrms.

- Connect an AC milli-voltmeter to TP601 (+) and TP602 (-).
   (Use TP602 for ground lead.)
- 2. Put the unit in recording mode.
- 3. Adjust R634 so that the AC milli-voltmeter read is 2.5 ± 0.1mVrms.

# CHECKING OF ERASE VOLTAGE AND OSCILLATION FREQUENCY

Measuring instrument	Oscilloscope
Mode	Record
Test point	Full erase head
Control	T601
Specification	70 ± 5kHz,40Vp-p or greater.

- 1. Put the unit in record mode.
- 2. Connect an oscilloscope across the full erase head.
- 3. Make sure the erase voltage across the full erase head is approx. 40Vp-p or more and frequency is 70 ± 5kHz.




Figure 5-7.

### **RF CIRCUIT**

# ADJUSTMENT OF RF AGC CIRCUIT (EXCEPT G/S Version)

Measuring instrument	Oscilloscope
Mode	Good TV Commercial broadcast reception
Test point	TP1502 (Sig.), TP1501 (GND)
Control	VR001 AGC control
Specification	Just before shrinking (See of Figure 5-8.)

- Have the unit received good TV commercial broadcast reception.
   (Input field strength: 80dBμV of antenna torminal)
- 2. Connect an oscilloscope to test points TP1502 (Sig.) and TP1501 (GND).
- 3. Observe the video output terminal waveform on the oscilloscope.
  - Adjust VR001 (AGC control) in the IF pack until the noise disappears from the oscilloscope screen and the waveform nearly comes into sync.




Figure 5-8.


# ADJUSTMENT OF RF AGC CIRCUIT (G/S-Version ONLY)


Measuring instrument	DC voltmeter VHF signal generator
Mode	RF signal at E12-CH (by VHF signal generator) (EBU colour bar signal at 87.5% modulated.)
Test point	TP1503 (+), TP1501 (-)
Control .	VR001 AGC control
Specification	4.5 ± 0.1V (When the tuner make use of VTUVTSH6HZ50/) 4.5 ± 0.1V (When the tuner make use of VTUOF4EG-721F) 4.5 ± 0.1V (When the tuner make use of VTUOF4EG-721F)

1. Receive the E12 channel signal (colour bar signal at 87.5% modulated.) at input field strength: 70dBµV of antenna terminal.

- 2. Connect a DC voltmeter to test points TP1503 (+) and TP1501 (-).
- 3. Adjust VR001 (AGC control) in the IF pack so that the voltage be specified.

47.4








.


The second second


The MALESTA (B.C.)













12 Car 1 Com

# 7. TROUBLESHOOTING





Replace IC801.

9

Check between at pin (1) of receiver thru pin (15) of IC801

ΥES

## 15 Head

... O.E. ..

15/10/2015 PM

Replace IC5001.

KES

function?

Also negative voltage applied between these pins and GND.

YES


Is filament voltage applied


(19) and (20) of IC5001?

YES

YES

pin (18) of IC5001?







3. 3. 3.

se tužit**9**835 je spot<mark>ič</mark>a spotoboj se t Control of the Contro

1080 00 HOD





. G. . S. . . .


CLOSTED STABBLED STABLES OF SAME WORK


Replace IC801.

YES

YES

(1) of ME connector?






50


26 (10 PM)

C.080(); (

\* SAO LYONATLANDO.

ขอใช้ขานในปี





and the way up thru to pin (23) of

**IC401**.

Replace IC401.

Note: Words shown in the bracket " ( ) " are for the 2 head models only.

2


Is there a chroma signal at pin (27)


of IC401?

KES

IC4017

ΥES





### REPLACEMENT OF !C804 (E<sup>2</sup>PROM)

≪ Servicing precautions >>

When the IC804 (E<sup>2</sup>PROM) has been replaced, make the following reprogramming. Depending on models, the IC804 (E<sup>2</sup>PROM) has been factory adjusted for it's memory function. It's therefore necessary to reprogram the memory function for the model in question. Note that the servo circuit requires readjustments for the slow and still modes.

### Memory function reprogramming.

- 1. Check the power off. (Power is standby mode)
- 2. Make for a moment short circuited jumper pins 33 and 34 on the main PWB. Be sure that all the fluorescent display tubes light up into the TEST mode.
- 3. Using the CHANNEL (+) and (-) buttons, select the right function numbers from among JP0-JP31, which appear in the fluorescent display tube, referring to the E<sup>2</sup>PROM map.

  Press the DISPLAY button to pick up the functions (ON) and the CLEAR button to discard the functions (OFF).
  - \* When the DISPLAY button has been pressed (ON), the memory function No. starts flashing.
  - \* When the CLEAR button has been pressed (OFF), the memory function No. lights up.
- 4. Make the short circuited cathode of D5001 and jumper pin 391 on the main PWB, and the settings will be displayed in hexadecimal notation.

Now you can see if the settings are correct.

Example: "ON" and "OFF" are taken as "1" and "0" respectively. The numbers JP0 to JP31 are divided into eight groups and each group's setting is displayed in hexadecimal notation.

J31   0	0 0 SPACE			J20 J19 0   0	J18 J17 J 0 0 0	16 0
	J14 J13 0 0 0	J10 J9 1 0 4			J2 J1 1 0 D	J0 1

"000040D" appears in the fluorescent display tube.

5. Finally make for moment short circuited jumper pins 33 and 34 on the main PWB to clear the TEST mode or press the operate button to turn the power on.

A49GM A62GM A62SM A462GM A462SM A72GM  0 0 0 0 0 0 0 0 0  0 0 0 0 0 0 0 0  0 0 0 0 0 0 0 0  0 0 0 0 0 0 0 0  0 0 0 0 0 0 0 0  0 0 0 0 0 0 0  0 0 0 0 0 0 0  0 0 0 0 0 0 0  1 0 0 0 0		п	7			т-	<del></del>	_	_	т-	ı	_	_			1				_	,			<del></del>										
Ministration   Mini	A72LM	0		0	0	0	0	  -  -	0	0	0	0	0	0	0		i 	0	11111		- - - - - - -	-	1		0	-	0	0	0	-	0	0	0	2035E80
Microson   Masser	A72HM	0	0	0	0	0		1	0	0	0	0	0	0	0	  -  -		0		0	1	-	0	1	   	÷	0	-		÷-	0	0	0	2035BA8
Minker   Market   M	A72GM	0	0	0	0	0	0	1	0	°	0	0	0	0	0		0	0		0		-	       	0	0	-	0	0	0	1	         	0	         	2025C8D
Minker   Market   M	A462SM	0	0	0	0	0	0	1	0	0	0	0	0	٥	0	0	0	0	-	0	0	0	0	0	0	0	0	0	0	0		0		2004001
March   Marc	A462GM	0	0	0	0	0	0		0	0	0	0	0	0	0	0	0	0	-	0	0	0	0	0	0	0	0	0	0	1		0	1 1	200400D
March   Marc	A62SM	0	0	0	0	0	0	1	0	o	0	0	0	0	0	0	0	0		0	       	0	0	0	0	0	0	0	0	0	0.	0	1	2005001
March   Marc	A62GM	0	0	0	0	0	0	         	0	0	0	0	0	0	0	0	0	٥		0	         	0		0	0	. 0	0	0	0	-		0	1	200540D
Minks   Mink	A49GM	0	0	0	0	0	0	0	0	0	0	0	0	0	0		0	•	0	0	0	0		0	0	1	0	0	0	1		0	-	002048D
MI-FI	A50LM	0	0	0	0	0	0	0	-	0	0	0	0	0	0	       (	1	0	 	0	0	0		         	0	1	0	0	0	0	0	0	0	1034680
NI-PB	A50HM	0	0	0	0	0	0	0	  - 	0	0	0	0	0	0	-	-	0	-	0	0	0	0	     — 	       <del>  -</del> 	-	0	- I	0	0	0	0	0	10343A0
A39GM   A39SM   A239GM   A23		0	1 !	i i	0	0	0	 		0	0	0	0	0	0	0	0	0	-	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1004000
A39GM   A39SM   A239GM   A23	А39НМ	0	0	0	0	0	0	0		0	0	0	0	0	0	0	0	0		0	0	0	0	0	1	0	0		0	0	0	0	0	1004120
A39GM A39SM A239SM	A239GM	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	00	0	0	0	0	0	0	0	0	0	0	0	0			0	-	ш
A39GM  0  NT-PB 0  HEAD1 0  HEAD1 0  HEAD1 0  HEAD1 0  G-CODE0 0  G-CODE0 0  G-CODE0 0  CATV 1  TUNER 0  TU	A39SM A239SM	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-	—
NT-PB HEAD1 HEAD1 HEAD1 HEAD1 HEAD0 OEM G-CODE0 OEM LP TUNE2 CATV TUNER	A39GM	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-	0	0	0	0	0	0	- I	-	0	1	⊢
						NT-PB	- I	HEAD1	HEAD0		1		:	4-51	MCAM	GCODE1	3-CODE0	DEM	طر ا ا	- I	HUTTLE	INEZ	ATV	UNER1	UNERO	ECODER	YSTEM-I	CR1	GR0	2	PS	OLOUR1	OLOURO	$\vdash$
		JP31	30	59	$\dashv$					23	22	21	_	_				2				=	0,	٥¦		•				$\overline{}$	$\overline{}$		_	

(Note: "1" : flashing "0" : lights up)

REPL «Serri Wheatl Depend It's fat Note ti

r straffi


4004 5


jakaj 18 Luni Luni Luni Propi


is in Ja Jugob wovi

e 25 🗗

# 8. BLOCK DIAGRAM SERVO PROCESS BLOCK DIAGRAM







# **MEMO**

### **SCHEMATIC DIAGRAM**

**IMPORTANT SAFETY NOTICE:** 

BE SURE TO USE GENUINE PARTS FOR SECURING
THE SAFETY AND RELIABILITY OF THE SET
PARTS MARKED WITH "A" AND PARTS SHADED
(IN BLACK) ARE ESPECIALLY IMPORTANT FOR
MAINTAINING THE SAFETY AND PROTECTING
ABILITY OF THE SET.

BE SURE TO REPLACE THEM WITH PARTS OF SPECIFIED PART NUMBER.

### **SAFETY NOTES:**

- 1. DISCONNECT THE AC PLUG FROM THE AC OUTLET BEFORE REPLACING PARTS.
- 2. SEMICONDUCTOR HEAT SINKS SHOULD BE REGARDED AS POTENTIAL SHOCK HAZARDS WHEN THE CHASSIS IS OPERATING.

### NOTES:

- 1. The unit of resistance "ohm" is omitted (k = 1000 ohm, M = 1 Meg ohm).
- 2. All resistors are 1/8 watt, unless otherwise noted.
- 3. The unit of capacitance "F" is omitted ( $\mu = \mu F$ ,  $p = \mu \mu F$ ).
- 4. The values in parentheses are the ones in the PB mode; the values without parentheses are the ones in the REC mode.

### **VOLTAGE MEASUREMENT CONDITIONS:**


- 1. DC voltages are measured between points indicated and chassis ground by VTVM, with AC230V, 50Hz supplied to unit and all controls are set to normal viewing picture unless otherwise noted.
- 2. Voltages are measured with 10000µV B & W or colour signal.


WAVEFORM MEASUREMENT CONDITIONS: 10000μV 87.5 percent modulated colour bar signal is fed into tuner.

### CAUTION:


This circuit diagram is original one. Therefore there may be a slight difference from yours.

# 9. CIRCUIT DIAGRAM AND PWB FOIL PATTERN MAIN (1) / OPERATION / REMOTE CONTROL RECEIVER CIRCUIT








PB ...... Parentheses ( ) **REC ..... Without Parentheses** 




PB ...... Parentheses ( )
REC ..... Without Parentheses









Many electrical and mechanical parts in video cassette recorder have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this manual; electrical components having such features are identified by A and shaded areas in the Replacement Parts Lists and Sche matic Diagrams. The use of a substitute replacement part which does not have the same safety characteristics as the factory recommended replacement parts shown in this service manual may create shock, fire or other hazards.

#### "HOW TO ORDER REPLACEMENT PARTS"

To have your order filled promptly and correctly, please furnish the following informations.

1. MODEL NUMBER


2. REF. NO.

3. PART NO.

4. DESCRIPTION

5. PRICE CODE

## **HOW TO IDENTIFY CHIP TRANSISTORS AND DIODES BY ITS MARKING**



Package	Marking	Parts No.
Fig. 1	15	VSDTA124EK/-1
Fig. 1	25	VSDTC124EK/-1
Fig. 1	24	VSDTC114EK/-1
Fig. 1	26	VSDTC144EK/-1
Fig. 1	16	VSDTA144EK/-1
Fig. 1	BQ	V\$2\$C2412KQ-1

MARK ★: SPARE PARTS-DELIVERY SECTION. Description Code Ref. No. Part No.

## PRINTED WIRING BOARD ASSEMBLIES (NOT REPLACEMENT ITEM)

DUNTK4928TEV6 - Main Unit (VC-A462GM) --DUNTK4928TEV8 - Main Unit (VC-A462SM) --DUNTK4929TEV2 - Operation Unit DUNTK4930TEV1 - R/C Receiver Unit

Ref. No	. Part No. * Description	Code	Ref. No.	Part No.	<b>★</b> Descriptio	n Code	Ref. No.	Part No.	* Description	Code
-	NINTE/AD20TEV6 (VC AA62CE	7		TRANSISTO	R (Continued)			DIODES (	Continued)	
	OUNTK4928TEV6 (VC-A462GI		Q957	VSDTC124EK/-	J DTC124EK	AB	D957	RH-DX0053GEZZ	. J 1SS132	AΑ
D	DUNTK4928TEV8 (VC-A462SN	A)	Q958	V\$2\$A950-Y/1	J 2\$A950	AD	D958	RH-DX0053GEZZ	. J 1\$\$132	ĄΑ
	MAIN UNIT ASSEMBLY		Q959	VSDTC124EK/-	I J DTC124EK	AB	D959	RH-DX0053GEZZ	. J 1SS132	Α̈́A
		4	Q960	VS2SC2001LK-	1 J 2SC2001LK	AA	D960	RH-EX0291CEZ	Z J Zener Diode	ĄΑ
	TUNER AND ASSEMBLY	. 17.		VS2C1740SQR1E	J 25C1740SQR	AĈ	D2201	RH-EX0168GEZ	Z J HZ\$15EB2	ĄĀ
CBD (44)	51 RCNVR0133GEZZ J RFConverter	4.7		V\$2\$C2412KQ-		AA	D2401	RH-DX0053GEZZ	. J 1SS132	ĀA
		AZ	•	VS2SA1037KQ-	•	AA	D4401	RH-EX0168GEZ	Z J HZS15EB2	ÄA
	51 VTUOF4EG-721/ U VHFTuner		Q8851	<del>-</del>		AB	D5001	RH-DX0053GEZZ	. J 1SS132	AA
UNT15	51 RİFU-0624GEZZ JIF-Pack	BB	· ·	VSDTA144EK/-1		AC		RH-DX0053GEZZ		ÅA
					•			RH-DX0053GEZZ		ĄΑ
	INTEGRATED CIRCUITS		* p*					RH-DX0053GEZ		AΑ
10204				DI	DDES			RH-EX0168GEZ		AA
IC301		AL	D301	RH-DX0053GEZZ		AA		RH-DX0053GEZ		AΑ
IC401		AW	D302	RH-DX0053GEZZ		AA	<u> </u>	RH-FX0005GEZ		AE
IC402	·	AM ;	D330	RH-DX0053GEZ		AA	Q851	RH-PX0233GEZ		AD
IC601		AG	D331	RH-DX0053GEZ		AA	O852	RH-PX0233GEZ		AD
IC701		AF	D331	RH-DX0053GEZ		AA	QUUL	KII-I XUZUUUL	E 3 Thoto bloge	70
IC801	RH-iX0867GEZZ   Syscon/Servo/Timer	BE	D540	RH-DX0053GEZ	· ·	AA	* .	PACKAGI	D CIRCUITS	
IC802	VHiS806HZ//-1 J Reset	AC	D540	RH-DX0053GEZ		AA	X501		. J Crystal, 4.43MHz	AF
IC803	B VHIBA6209//1E J Loading Motor Drive	r AG	D541 D542	RH-DX0053GEZ		AA	X801		J Crystal, 10MHz	AM
IC804	VHILE93C46T-1 J E <sup>2</sup> PROM	AF		RH-DX0053GEZ					J Crystal (GM only)	AG
IC951	VHiUZT33///-1 J AT33V Regulator	AC ;	D602			AA	X1001	KCK3601/3GEZ	. J Crystai (Givi Olliy)	AG
IC145	51 RH-iX0203GEZZ J Band Switch	AE	D701	RH-DX0053GEZ		AA				
IC180	01 VHiMV1821MP-1 U VPS/PDC Decoder	AW	D702	RH-DX0053GEZ		AA		COUCANDT	DANCEODRAFDO	
	(VC-A462GM)		D703	RH-DX0053GEZ		AA	~. ~		RANSFORMERS	
IC240	01 VHILA7217M/-1 J	AG	D704	RH-DX0053GEZ	·	AA		RFILA0020CEZ		AD
IC500	01 VHiMN12510F-1 J FLP Driver	AM	D <b>705</b>	RH-DX0053GEZ		AA		RFILC0115GEZ		AC
			D706	RH-DX0053GEZ		AA	L201	VP-XF151K000		AΒ
	TRANSISTORS		D707	RH-DX0053GEZ	Z J 1\$\$132	AA	L202	VP-XF150K000	•	AB
Q201	V\$2\$A1037KQ-1 J 2\$A1037KQ	AA	D801	RH-DX0053GEZ	Z J 1S\$132	AA	L203	VP-XF330K000	· ·	AB
Q202	VS2SC2412KQ-1 J 2SC2412KQ	AA	D802	RH-DX0053GEZ		AA	L204	VP-XF120K000	O J 12μΗ	AB
Q203	V\$2\$C2412KQ-1 J 2\$C2412KQ	AA	D851	RH-PX0234GEZ	Z J Photo Diode	AD	L205	VP-XF820K000	) Ј 82µН	AB
Q204		AA	D854	RH-PX0231GEZ	Z J GP1S24	AF	L206	VP-DF1R2M000	) J 1.2μH	AB
Q205	-	AA	D855	RH-PX0231GEZ	Z J GP1S24	AF	L207	VP-XF560K000	) J 56µH	AB
Q540		AB	D856	RH-PX0232GEZ	Z J Photo Diode	AF	L208	VP-XF151K000	D J 150μH	AB
Q541		AA 1	D857	RH-PX0232GEZ	Z J Photo Diode	AF	L209	VP-XF560K000	D J 56μH	AB
_	VSDTA124EK/-1 J DTA124EK	AB	<u> </u>	RH-DX0083GEZ	Z J Diode	AC	L210	VP-XF151K000	O J 150μH	AB
Q543		AB :	<u> </u>	VHDERA2206/-	1 J ERA2206	AC	L301	VP-DF101K000	O J 100μH	AB
Q544		AB	<b>▼</b> D903	RH-DX0220CEZ	Z J Diode	AB	L302	VP-DF101K000	0 J 100μH	AB
Q601		AA	<u> </u>	RH-DX0052GEZ	Z J Diode	AB	L501	VP-MK561K000	<b>0</b> J <b>560</b> μH	AB
Q602		AA	<u> </u>	RH-DX0053GEZ	Z J 1SS132	AA	L504	VP-Xf150J000	0 J 15μH	AB
Q603		AC	<b>∆</b> D906	RH-EX0279CEZ	Z J UZ3.0BSA	AA	L505	VP-XF100K000	0 J 10μH	AB
Q702		AA	<u> </u>	VHDFR103///-	1 J FR103	AC	L506	VP-XF390J000	0 Ј 39µН	AB
-	325A1037KQ-1 J 25A1037KQ		<u> </u>	VHDFR103///-	1 J FR103AC	AC	L507	VP-YF682J000	0 J 6.8mH	AC
Q801		AA	<u> </u>	VHD30DF2-FC-	1 J 30DF2-FC	AD	L509	VP-XF151K000	O J 150µН	AB
	- · · · · · · · · · · · · · · · · · · ·	AA	<u> </u>	VHDRK34///-	I J RK34	AE	L510	VP-XF181K000	0 J 180µH	AB
	2 VSDTC114EK/-1 J DTC114EK	AA				AC	L511	VP-DF680K000	•	AB
<u>∧</u> Q901		AH	D926	RH-EX0807GEZ	Z J Zener Diode	AC	L601	VP-YF822J000	•	AC
<u>∧</u> Q902		AA	D927	RH-EX0294CEZ		AA	L602	VP-DF221K000		AB
Q921	·	AA	D928	RH-DX0053GEZ		AA	<b> ∆ L901</b>	RCiLF0227GEZ	•	AM
Q922		AA	D929	RH-DX0053GEZ		AA	<u> </u>	RCiLF0227GEZ		AM
Q923		ĄΑ	D930	RH-EX0301CEZ		AA	L921	RCiLP0171CEZ		AD
Q951		AA	D951	VHD1A3-F///-		AA	L922	RCILP0175CEZ	•	AD
	2 V\$2\$C2001LK-1 J 2SC2001LK	AA	D952			ĀĀ		VP-XF120K000	•	AB
	3 VS2SC2412KQ-1 J 2SC2412KQ	AA	D953	RH-EX0293CEZ		AA			0 J 12μΗ (GM only)	AB AB
0056	5 V\$2\$A950-Y/1E J 2\$A950	AD	•						· · · · · · · · · · · · · · · · · · ·	
Q330			D954	KM-FXII/MAI F/	Z J UZ-5.1BSB	AA	11557	VP_XE1206000	0 J 12μΗ (GM only)	AB

L1553 VP L1554 VP L1555 VP L1556 VP L1557 VP L1558 VP L1559 VP L1559 VP L1801 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	S AND TRANSFO  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF120K0000  P-XF2K0000  P-XF2R2K0000  CONT  VR-M4421GEZZ  CAPAC  CKYD41HB681K  CKYCY1HB391K  CCCCY1HH330J  CCCCY1HH330J  CCCCY1HH330J	)	12µH (( 12µH (( 12µH (( 12µH (( 12µH (( 12µH (( 8.2µH ( 8.2µH ( 2.2µH ( 2.2µH ( 2.2µH ( 2.2µH ( 100(B)))))))))))))))))))))))))))))))))))	GM or	nly) nly) nly) nly) nly) nly) only) only) only) only) ormer r  Current		AB AB AB AB AB AB AB AB AB AB AB AB	C239 C240 C242 C243 C244 C301 C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCCCCY VCKYCY	(1114 (1118) (1114) (11	560J 391K 560J 330J 221J 223Z 223Z 104Z 223Z 223Z 223Z 223Z 223Z 476M 103Z 476M 103Z 476M 103Z 476M 103Z 476M 104Z 104Z		390p 56P 33p 220p 0.022 0.022 0.1 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 50V 50V 50V 50V 25V 25V 50V 50V 6.3V 50V 16V 50V 50V 50V 25V 25V 25V	Ceramic	AA AB AA AA AA AA
L1553 VP L1554 VP L1555 VP L1556 VP L1557 VP L1558 VP L1559 VP L1559 VP L1801 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF2K0000 P-XF2R2K0000 P-XF2R2	)	12µH (( 12µH (( 12µH (( 12µH (( 12µH (( 12µH (( 8.2µH ( 8.2µH ( 2.2µH ( 2.2µH ( 2.2µH ( 2.2µH ( 100(B)))))))))))))))))))))))))))))))))))	GM or	nly) nly) nly) nly) nly) nly) only) only) only) only) ormer r  Current		AB AB AB AB AB AB AB AB AB AB AB AB	C240 C242 C243 C244 C301 C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYCY VCCCCY VCKYCY	71HB3 71HH 71HH 71HF; Y1HF; Y1EF* Y1HF Y1HF Y1HF Y1HF Y1HF Y1HH Y1HH Y1HH	391K 560J 330J 221J 223Z 223Z 104Z 223Z 223Z 223Z 223Z 476M 103Z 476M 103Z 476M 103Z 476M 103Z		390p 56P 33p 220p 0.022 0.022 0.1 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 50V 50V 50V 50V 25V 50V 50V 6.3V 50V 16V 50V 50V 50V 50V 50V 25V	Ceramic	AA
L1554 VP L1555 VP L1556 VP L1557 VP L1558 VP L1559 VP L1801 VP L1802 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J CCCCCY1HH330J	J J J J J J J J J J J J J J J J J J J	12µH (и 12µH (и 12µH (и 12µH (и 12µH (и 12µH (и 8.2µH (и	GM or	nly) inly) i		AB A	C242 C243 C244 C301 C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCCCCY VCCCCY VCKYCY	71HH 71HH 71HF; Y1HF; Y1EF; Y1EF; Y1HF Y1HF Y1CF; A0JW4 Y1HF Y1HH Y1HH Y1HH Y1EF	560J 330J 221J 223Z 223Z 104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J		56P 33p 220p 0.022 0.022 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 50V 50V 50V 25V 25V 50V 50V 16V 50V 50V 50V 50V 50V 25V	Ceramic Electrolytic Ceramic	AA
L1555 VP L1556 VP L1557 VP L1558 VP L1559 VP L1801 VP L1802 VP L4401 VP L6601 VP L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF8R2K0000 P-XF8R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J CCCCCY1HH330J	)	12µH (112µH (112µH (112µH (112µH (112µH (112µH (112)µH	GM of GM of GM of GM of (GM of (GM of (GM of ansforomer	only) only) only) only) only) only) only) only) only) ormer r  Current		AB A	C243 C244 C301 C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCCCCY VCKYCY	Y1HH Y1HF: Y1HF: Y1EF: Y1EF: Y1HF Y1HF Y1CF: A0JW4 Y1HF Y1CHH Y1HH Y1HH Y1EF	330J 221J 223Z 223Z 104Z 104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z		33p 220p 0.022 0.022 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 33p 0.1	50V 50V 50V 25V 25V 50V 50V 16V 50V 50V 50V 50V 50V 25V 25V	Ceramic	AA AA AA AA AA AA AA AA AA
L1556 VP L1557 VP L1558 VP L1559 VP L1801 VP L1802 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF8R2K0000 P-XF8R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	)	12µH (1 12µH (1 12µH (1 12µH (1 8.2µH (2 4.7µH (2 2.2µH (2 2.2µH (2 2.2µH (3) 100(B) 100(B) 100(B)	GM of GM of GM of (GM of (GM of (GM of ansfo ormer	only) only) only) only) only) only) only) ormer r  Current		AB A	C244 C301 C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCCCCY VCKYCY VCKYCY VCKYCY VCKYCY VCKYCY VCKYCY VCEAGA VCKYCY VCCCCY VCCCCY VCKYCY VCCCCY VCKYCY VCCCCY VCKYCY	Y1HH Y1HF; Y1EF; Y1EF; Y1HF Y1HF Y1HF Y1HF Y1HF Y1HH Y1HH Y1HH	221J 223Z 223Z 104Z 104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 104Z 104Z	11111111111111111	220p 0.022 0.022 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 50V 50V 25V 50V 50V 16V 6.3V 50V 16V 50V 50V 25V 25V	Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AA AB AA AA AA AA AA
L1557 VP L1558 VP L1559 VP L1801 VP L1802 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF120K0000 P-XF120K0000 P-XF8R2K0000 P-XF8R2K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	) ) ) ) ) ) ) ( ) )	12µH ( 12µH ( 12µH ( 8.2µH ( 4.7µH ( 2.2µH ( 2.2µH ( 2.2µH ( 5.2)µH ( 1.2)µH ( 1.2)	GM of GM of (GM of (GM of (GM of (GM of ansforomer	only) only) only) only) only) only) only) only) ormer r  Current		AB AB AB AB AB AB AB AB AB	C301 C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYCY VCKYCY VCKYCY VCKYCY VCKYCY VCKYCY VCEAGA VCKYCY VCEAGA VCKYCY VCCCCY VCCCCY VCKYCY VCKYCY VCKYCY	Y1HF; Y1HF; Y1EF; Y1HF Y1HF; Y1HF; Y1CF; Y1HF; Y1HH; Y1HH; Y1HH; Y1HH; Y1EF;	223Z 223Z 104Z 104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z		0.022 0.022 0.1 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 50V 25V 25V 50V 50V 16V 50V 16V 50V 50V 50V 25V 25V	Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AA AB AA AA AA AA
L1558 VP L1559 VP L1801 VP L1802 VP L4401 VP L6601 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF120K0000 P-XF8R2K0000 P-XF8R2K0000 P-XK4R7K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J CCCCCY1HH330J	I I I I I I I I I I I I I I I I I I I	12µH (4 12µH (4 8.2µH (4 4.7µH (220µH (2.2µH	GM of GM of (GM of (GM of (GM of ansforormer	only) only) only) only) only) only) only) ormer r  Current		AB AB AB AB AB AB AE AR	C302 C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYCY VCKYCY VCKYCY VCKYCY VCKYCY VCEAGA VCKYCY VCEAGA VCKYCY VCCCCY VCCCCY VCKYCY VCKYCY VCKYCY	Y1HF; Y1EF; Y1HF Y1HF; Y1HF; Y1CF; A0JW4 Y1HF X1CW4 Y1HH Y1HH Y1HH Y1EF	223Z 104Z 104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z	111111111111111	0.022 0.1 0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 25V 25V 50V 50V 16V 6.3V 50V 50V 50V 50V 25V	Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AA AA AA AA
L1559 VP L1801 VP L1802 VP L4401 VP L6601 VP L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF120K0000 P-XF8R2K0000 P-XF8R2K0000 P-XK4R7K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J	I I I I I I I I I I I I I I I I I I I	12µH (68.2µH (4.7µH (2.20µH (2.2µH (2	(GM of (GM of (G	only) only) only) only) only) only) ormer r  Current		AB AB AB AB AB AE AR	C303 C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYCY VCKYCY VCKYCY VCKYCY VCEAGA VCKYCY VCEAGA VCKYCY VCCCCY VCCCCY VCKYCY VCKYCY	Y1EF' Y1HF Y1HF Y1HF Y1CF: A0JW- Y1HF A1CW- Y1HF Y1HH Y1HH Y1EF Y1EF	104Z 104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z	1111111111111	0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	25V 25V 50V 50V 16V 6.3V 50V 50V 50V 25V 25V	Ceramic Ceramic Ceramic Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AA AA AA
L1801 VP L1802 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF8R2K0000 P-ZK4R7K0000 P-ZK4R7K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCCY1HH330J	1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 :	8.2µH (4.7µH (2.20µH (2.2µH (2	(GM c (GM c (GM c (GM c (GM c ansfo ormer	only) only) only) only) only) only) ormer r  Current	5	AB AB AB AB AE AR	C304 C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYCY VCKYCY VCKYCY VCEAGA VCKYCY VCEAGA VCKYCY VCEAGA VCKYCY VCEAGA VCKYCY VCCCCY VCKYCY VCKYCY	Y1EF' Y1HF Y1HF Y1CF: A0JW4 Y1HF A1CW4 Y1HF Y1HH Y1HH Y1EF Y1EF	104Z 223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z	111111111111	0.1 0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	25V 50V 50V 50V 16V 6.3V 50V 50V 50V 25V	Ceramic Ceramic Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AA AB AA AB AA AA AA
L1802 VP L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-ZK4R7K0000 P-MK221K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J	I I I I I I I I I I I I I I I I I I I	4.7μH 220μH 2.2μH 2.2μH 2.2μH Osc. Tr Transfo 100(B) ORS 680p 390p	(GM of GM of	only) only) only) only) ormer r  Current	5	AB AB AB AE AR	C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYCTVCKYCTVCEAGAVCKYCTVCEAGAVCKYCTVCCCCTVCKYCTVCCTVCKYCTVCCTVCCTVCCTVCCTVCCTVCCTVCCTVCCTVCCTV	Y1HF Y1HF Y1CF: 40JW4 Y1HF 41CW4 Y1HF Y1HH Y1HH Y1EF	223Z 223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z 104Z	111111111111	0.022 0.022 0.022 0.33 47 0.01 47 0.01 33p 0.1 0.1	50V 50V 50V 16V 6.3V 50V 50V 50V 25V 25V	Ceramic Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AB AA AB AA AA AA
L4401 VP L6601 VP L6602 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-MK221K0000 P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	I I I I I I I I	220µH 2.2µH 2.2µH 0sc. Tr Transfo 100(B) 0RS 680p 390p	(GM c (GM c (GM c ransfo ormer	only) only) only) ormer r Current	5	AB AB AB AE AR	C307 C308 C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYC VCKYC VCEAGA VCKYC VCEAGA VCKYC VCCCC VCCCC VCKYC	Y1HF Y1HF Y1CF: A0JW4 Y1HF A1CW4 Y1HF Y1HH Y1HH Y1EF Y1EF	223Z 223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z 104Z	111111111111111111111111111111111111111	0.022 0.022 0.33 47 0.01 47 0.01 33p 33p 0.1	50V 50V 16V 6.3V 50V 50V 50V 50V 25V	Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AA AB AA AA AA AA
L6601 VP L6602 VP L6603 VP T601 RT  ▲ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF2R2K0000 P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	J J U FRC J STC	2.2µH 2.2µH 2.2µH Osc. Tr Transfo )L 100(B) ORS 680p 390p	(GM c (GM c (GM c ransfo ormer	only) only) ormer r Current	5	AB AB AE AR	C309 C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYC VCEAGA VCKYC VCEAGA VCKYC VCCCC VCCCC VCKYC VCKYC	Y1HF Y1CF: 40JW/ Y1HF 41CW/ Y1HF Y1HH Y1HH Y1EF	223Z 334Z 476M 103Z 476M 103Z 1330J 1330J 104Z 104Z	111111111111111111111111111111111111111	0.022 0.33 47 0.01 47 0.01 33p 33p 0.1 0.1	50V 16V 6.3V 50V 16V 50V 50V 25V	Ceramic Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic	AA AB AA AA AA AA
L6602 VP L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF2R2K0000 P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	I U I I I I I I I I I I I I I I I I I I	2.2µH 2.2µH Osc. Tr Transfo  >L 100(B)  >RS 680p 390p	(GM c (GM c ransfo ormer Bias (	only) only) ormer r Current	5	AB AE AR AB	C310 C311 C312 C314 C315 C330 C331 C332 C333	VCKYC VCEAGA VCKYC VCEAGA VCKYC VCCCC VCCCC VCKYC	Y1CF: 40JW4 Y1HF 41CW4 Y1HF Y1HH Y1HH Y1EF Y1EF	334Z 476M 103Z 476M 103Z 1330J 1330J 104Z 104Z	111111111111111111111111111111111111111	0.33 47 0.01 47 0.01 33p 33p 0.1 0.1	16V 6.3V 50V 16V 50V 50V 25V	Ceramic Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AB AA AA AA AA
L6603 VP T601 RT  ↑ T901 RT  R634 RV  C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	P-XF2R2K0000 TRNH0053GEZZ TRNZ0043UMZZ  CONT VR-M4421GEZZ  CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J CCCCY1HH330J	J U IRC	2.2µH Osc. Tr Transfo )L 100(B) )RS 680p 390p	(GM cransfo ormer Bias (	only) ormer r Current	5	AE AR AB	C311 C312 C314 C315 C330 C331 C332 C333	VCEAGA VCKYC VCEAGA VCKYC VCCCC VCCCC VCKYC	40JW4 Y1HF 41CW4 Y1HF Y1HH Y1HH Y1EF	476M 103Z 476M 103Z 1330J 1330J 104Z 104Z	1111111	47 0.01 47 0.01 33p 33p 0.1	6.3V 50V 16V 50V 50V 50V 25V	Electrolytic Ceramic Electrolytic Ceramic Ceramic Ceramic Ceramic Ceramic	AB AA AA AA AA AA
T601 RT  ↑ T901 RT  R634 RV  C201 VC  C202 VC  C203 VC  C204 VC  C205 VC  C206 VC  C208 VC  C209 VC	CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCCCY1HH330J	J U IRC J ITC J	Osc. Transformation of the control o	ansfo ormei Bias (	ormer r Current	5	AR AB	C312 C314 C315 C330 C331 C332 C333	VCKYC VCEAGA VCKYC VCCCC VCCCC VCKYC	Y1HF \1CW4 Y1HF Y1HH Y1HH Y1EF Y1EF	103Z 476M 103Z 1330J 1330J 104Z 104Z	111111111111111111111111111111111111111	0.01 47 0.01 33p 33p 0.1 0.1	50V 16V 50V 50V 50V 25V 25V	Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic Ceramic	AA AB AA AA AA AA
↑ T901 RT	CONTO CAPACE CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J CCCCY1HH330J CCCCY1HH330J CCCCY1HH330J	U IRC J IFC J	)L 100(B) )RS 680p 390p	Bias (	Current	5	ΑВ	C314 C315 C330 C331 C332 C333	VCEAGA VCKYC VCCCC VCKYC VCKYC	\1CW/ Y1HF Y1HH Y1HH Y1EF Y1EF	476M 103Z 1330J 1330J 104Z 104Z	1 1 1 1 1 1	47 0.01 33p 33p 0.1 0.1	16V 50V 50V 50V 25V 25V	Electrolytic Ceramic Ceramic Ceramic Ceramic	AB AA AA AA AA
C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC	CONT VR-M4421GEZZ CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	ITC	)L 100(B) )RS 680p 390p	Bias (	Current	5		C315 C330 C331 C332 C333	VCKYC VCCCC VCKYC VCKYC	Y1HF Y1HH Y1HH Y1EF Y1EF	103Z  330J  330J 104Z 104Z	1 1 1	0.01 33p 33p 0.1 0.1	50V 50V 50V 25V 25V	Ceramic Ceramic Ceramic Ceramic	AA AA AA AA
C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	J <b>ITC</b> J J J	100(B)  ORS  680p 390p	50V	Cerami	5		C330 C331 C332 C333	VCKYC	Y1HH Y1HH Y1EF Y1EF	330J 330J 104Z 104Z	] ] ]	33p 33p 0.1 0.1	50V 50V 25V 25V	Ceramic Ceramic Ceramic Ceramic	AA AA AA AA
C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	J <b>ITC</b> J J J	100(B)  ORS  680p 390p	50V	Cerami	5		C331 C332 C333	VCKYC VCKYC	Y1HH Y1EF Y1EF	1330J 104Z 104Z	]	33p 0.1 0.1	50V 25V 25V	Ceramic Ceramic Ceramic	AA AA AA
C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	3 <b>TC</b> 3 3	ORS 680p 390p	50V	Cerami	5		C332 C333	VCKYC VCKYC	Y1EF Y1EF	104Z 104Z	ì	0.1 0.1	25V 25V	Ceramic Ceramic	AA AA
C201 VC C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CAPAC CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	3 <b>TC</b> 3 3	ORS 680p 390p	50V	Cerami	5	AA	C333	VCKYC	Y1EF	104Z	J	0.1	25V	Ceramic	AA AA
C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	) )	390p			ić '	AA							_		AA
C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CKYD41HB681K CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	) )	390p			ić ′	AA	C22/	1101111	Y1HF	2227	· J	0.022	50V	Ceramic	
C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	) J	390p			ić (	AA	Coom	VCKYC		2232		U.UZ.Z			
C202 VC C203 VC C204 VC C205 VC C206 VC C208 VC C209 VC	CKYCY1HB391K CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	) J	•	50V	<b></b> .			 C335	VCKYC	Y1HF	223Z	j	0.022	50V	Ceramic	AA
C203 V C C204 V C C205 V C C206 V C C208 V C C209 V C	CCCCY1HH330J CCSD41HL150J CCCCY1HH330J	J	33p		Cerami	iC	AA	C336	VCKYC	Y1HF	223Z	J	0.022	50V	-Ceramic 🖂	AA
C204 V C C205 V C C206 V C C208 V C C209 V C	CCCCY1HH330J	ij		50V	Cerami	ic	AA	C337	VCKYC	Y1HB	102K	j	∍1000 <sub>l</sub>	5 <b>0V</b>	Ceramic	AA
C205 V C C206 V C C208 V C C209 V C			15p	50V	Ceram	ic	AA	C338	VCKYC	Y1HB	472K	J	4700	p <b>50V</b>	Ceramic	AA
C206 V C C208 V C C209 V C		J	33p	50V	Ceram	ic	AA	C339	VCKYC	Y1HB	102K	J	1000	p <b>50V</b>	Ceramic	AA
C208 V C	CCCCY1HH560J	J	56P	50V	Ceram	ic	AA	C340	VCKYC	Y1HF	103Z	J	0.01	50V	Ceramic	AA
C209 V C	CCCPA1HH560J	J	56p	50V	Ceram	ic	AA	C341	VCKYC	Y1HF	103Z	J	0.01	50V	Ceramic	AA
	CKYCY1CF334Z	J	0.33	16V	Ceram	ic	AA	C501	VCKYC	Y1HB	332K	J	3300	p50V	Ceramic	AA
C210 VC	CKYD41CY103N	J	0.01	16V	Ceram	ic	AA	C503	VCKYC	<b>Y1</b> HF	103Z	j	0.01	50V	Ceramic	AA
	CCCPA1HH390J		39p	50V	Ceram	ic	AA	C504	VCEAE.	WL0A	476M	J	47	6.3\	/ Electrolytic	: AB
	CEAEA1HW474M	J	0.47	50V	Electro	lytic	AB	C505	VCKYC	Y1HF	473Z	J	0.047	7 50V	Ceramic	AA
	CKYPA1HF473Z			50V	Ceram	ic	AA	C506	VCKYC	Y1HF	F103Z	J	0.01	50V	Ceramic	AA
	CEAEA1HW224M						ΑB	C508	VCKYD	41CY	103N	J	0.01	16V	Ceramic	AA
	CCCPA1HH101J						AA	C509	VCKYC	Y1EB	153K	j	0.015	25V	Ceramic	AA
	CCCCY1HH100D				Ceram		AA	C510	VCEAG	A1HW	/335M	j	3.3	50V	Electrolytic	: AB
	CEAEA1HW105M			50V	Electro	olytic	ΑB	C511	vcccc	Y1HE	43301	J	33p	50V	Ceramic	AA
	CKYD41CY103N				Ceram	-	AA	C512	VCKYO	Y1H1	F103Z		0.01	50V	Ceramic	AA
	CKYCY1EB223K			25V	Ceram	ic	AA	C513	VCKYO	Y1EF	104Z	J	0.1	25V	Ceramic	AA
	CEAEA1HW355M				Electro		ΑВ	C514	VCKYO	Y1H1	F333Z	. J	0.033	3 50V	Ceramic	AA
	CKYCY1EB223K						AA	C515	VCKY	CY1CI	F683Z	ز :	0.068	3 16V	Ceramic	AA
	CKYCY1EF104Z				Ceram		AΑ	C516	VCEAE	A1HW	/475M	J	4.7	50V	Electrolytic	c AB
	CEAEA1HW355M			50V	Electro	olytic	AB	C517	vcccc	Y1HI	H180.	;	18p	50V	' Ceramic	AA
	CEAEA1HW225M			50V				C519	VCKY	CY1H	F1032	<u>.</u>	0.01	50V	Ceramic	AA
	CEAEA1HW474M			50V		•		C520	VCEAE	A1HW	/474M	ļ	0.47	50V	Electrolytic	c AB
	CEAEA1HW224M			50V		-		C521	VCKY	Y1EB	3223K		0.02	2 25V	Ceramic	AA
	CKYCY1EF104Z				Ceran	-	AA	C522	vccc	CY1HI	H680.	١.	J 68p	50V	Ceramic	AA
	CEAEA0JW476M				/ Electr		AB	C523	VCEAE					16V	' Electrolytic	с АВ
	CEAEA1HW105M			50V		•		C524	vccc	CY1H	H820.	J.	J 82p	50V	Ceramic	AA
	CKYCY1HF473Z					•	AA	C525		A1HW	V105M	١.	J 1	50V	Electrolytic	с АВ
	CEAEA0JW476M				/ Electr		AB	C526		CY1H	H680.	J.	J 68p	50V	/ Ceramic	AΑ
	CKYCY1EF104Z				Ceran		ΑĄ	C527		CY1H	H470	١.	J 47p	50\	/ Ceramic	AA
	CCCCY1HH330				Ceran		AA	C528		CY1H	H560	j,	J 56P	50\	/ Ceramic	AA
	CCCD41HH4R7K				Ceran		AA	C529		A1HV	V475N	1	J 4.7	50\	/ Electrolytic	c AB

Ref. No.	Part No.	*	Desc	ription	Code	: Ref. No.	Part No.	*	Description	Code
	CAPACITORS	(C	ontinued	)			CAPACITORS	((	Continued)	
/⊊ ≠ <b>C530</b> ±	VCCCPA1HH121J	J	120p 50V	Ceramic	AA	C725			4700p50V Ceramic	AA
. C531	VCCSD41HL010M	-		Ceramic	AΑ	C726	VCKYCY1HF103Z			AA
. C532	VCCCCY1HH470J			Ceramic	AA	: C727	VCEAEA0JW107M			
C533	VCCCCY1HH470J				AA	. C728			4700p50V Ceramic	AA
C535	VCCCCY1HH181J		-		AA	C729	VCKYCY1HF103Z			AA
C536	VCCCCY1HH181J	J	180p 50V	Ceramic	AA	C730	VCEAEA0JW336M			
C537	VCKYD41CY103N	J	0.01 16V	Ceramic	AA	C731			1000p50V Ceramic	AA
C601	.VCKYCY1HB152K	J	1500p50V	Ceramic	AΑ	C732	VCFYSA1HB334J			AB
C602	VCKYD41CX332N	J	3300p16V	Ceramic	AA	C733	VCKYCY1CF334Z			AA
C603	VCEAAA1HW475T		4.7 50V	Electrolytic	AB	C734			0.047 50V Ceramic	AA
C604	VCEAGA1CW226M				AB	C736	VCKYCY1HF103Z			AA
<sub>64</sub> C605	VCQYTA1HM123J		0.012 50V	Mylar	AA	C737	VCKYCY1HF103Z			AA
C606	VCKYCY1HB682K		•	Ceramic	AA	C738	VCEAEA1HW105M			
C607	VCEAGA1CW476M			Electrolytic	AB	C740	VCKYCY1HB472K	j		AA
C608	RC-KZ0029GEZZ	J	0.01 25V	Ceramic	AA	C801	VCCCCY1HH470J	J		AA
C609	RC-KZ0029GEZZ		0.01 25V	Ceramic	AA	C802	VCCCCY1HH470J			AA
<sub>اس</sub> C610	VCEAGA1CW226M		22 16V	Electrolytic	AB	C803	VCCCCY1HH470J			AA
£ <sub>6</sub> ∧ <b>C611</b> .	VCEAGA1CW106M		.10 16V	Electrolytic	AA	C805	VCEAEA1HW105M			
∌ <sub>2</sub> <b>C612</b>	VCKYCY1EB223K		0.022 25V	Ceramic	AA	C807	VCCCCY1HH220J	J	22p 50V Ceramic	AA
C613	VCKYCY1HF103Z	J	0.01 50V	Ceramic	AA	C808	VCCCCY1HH220J		22p 50V Ceramic	AA
C614	VCCCCY1HH151J	J	150p 50V	Ceramic	AA	C811	VCKYCY1HF103Z		0.01 50V Ceramic	AA
C615	VCCCCY1HH151J	J	150p 50V	Ceramic	AA	C812	VCKYCY1HF103Z			AA
C616	VCKYCY1HB331K	į	330p 50V	Ceramic	AA	C813	VCKYCY1HF103Z			AA
C617	VCCCCY1HH220J	j	22p 50V	Ceramic	AA	C817			1000P50V Ceramic	AA
C618	VCEAGA1CW106M	J	10 16V	Electrolytic	AA	C819			1000 6.3V Electrolytic	
C619	VCKYCY1HB821K	j	820p 50V	Ceramic	AA	C820	VCKYCY1EF104Z			AA
C621	VCEAGA1CW476M	J	47 16V	Electrolytic	AB	C821	VCCCCY1HH101J			AA
C622	VCKYCY1HF103Z	J	0.01 50V	Céramic	AA	C822	VCKYCY1CF334Z			AA
C623	VCKYCY1HF103Z	J	0.01 50V	Ceramic	AA	C823	VCKYCY1HF103Z			AA
C624	VCQPSA2AA562J	J	5600p100\	Mylar	AC	C824	VCEAGA1CW476M		47 16V Electrolytic	
C625	VCRYPA1HA221J	J	220p 50V	Ceramic	AB	C825	VCKYCY1EF104Z			AA
C626	RC-KZ0029GEZZ	j	0.01 25V	Ceramic	AA	C826	VCE9GA1HW105M		1 50V Elect. (N.P.)	
C701	VCKYCY1HB102K	J	1000p50V	Ceramic	AA	C829	VCKYD41CY103N			AA
C703	VCE9EA1HW105M	j	1 50V	Elect. (N.P.)	AC	<b>∆</b> C901	RC-FZ016SGEZZ			AK
C704	VCEAEA1HW105M	J	1 50V	Electrolytic	AB	<b></b> C902	RC-FZ008SGEZZ			AD
, C705	VCKYCY1HB102K	J	1000p50V	Ceramic	AA	<b> △ C90</b> 7	RC-KZ0070CEZZ			AD
C706	VCEAEA1HW225M			Electrolytic	AB	<u> </u>	RC-KZ0070CEZZ			AD
C707	VCKYCY1HB102K	J	1000p50V	Ceramic	AA	<u> </u>	RC-EZ0440GEZZ			
C708	VCKYCY1HF103Z	1	0.01 50V	Ceramic	AA	<b></b> €910	VCEAGA2AW225M		2.2 100V Electrolytic	
C709	VCEAEA0JW476M	J	47 6.3V	Electrolytic	AB	<b> ∆ C911</b>	VCFYAA2GA333K		0.033 400V M.Polypro	AD
C710	VCEAEA1CW106M	J	10 16V	Electrolytic	AB	<b> C</b> 912	RC-KZ0112CEZZ		100p 1kV Ceramic	AB
C711	VCKYCY1HF103Z	J	0.01 50V	Ceramic	AA	<b>▲</b> C913	VCQYTA1HM473J		0.047 50V Mylar	AA
C712	VCEAEA1HW225M		· -	Electrolytic	AB	<b> ⚠</b> C914	VCQYTA1HM473J		0.047 50V Mylar	AA
C713	VCEAEA1HW225M			Electrolytic	AB	<b> ⚠ C9</b> 15	VCQYTA1HM472J		4700p50V Mylar	AB
C714	VCEAEA1CW226M			Electrolytic	AB	C921	VCEAGA1AW477M		470 10V Electrolytic	
C715	VCKYD41HB102K	J	1000p50V	Ceramic	AA	C922	VCEAGA1HW476M		47 50V Electrolytic	
C716	RC-EZ0123GEZZ			Electrolytic	AB	C923	VCEAVA1CN228M		2200 16V Electrolytic	АН АН
. C717	VCEAEA1HW105M		1 50V	Electrolytic	AB	<b></b> C924	RC-QZ0104GEZZ		2200p250V Mylar	
C718	VCKYCY1HF103Z		0.01 50V	Ceramic	AA	C925			2200 10V Electrolytic	AC AE
C719	VCEAGA1HW105M	J	1 50V	Electrolytic	AC	<b>∆</b> C926	RC-QZ0104GEZZ	i	2200 250V Miles	AE
g# <b>C720</b>	VCKYCY1HB102K	J	1000p50V	-	AA	C927	VCQYTA1HM103J		-	AC
C721	VCKYCY1HF103Z			Ceramic	AA	C928	VCEAGA1CW107M			AA
. C722	VCKYCY1EF104Z	J		Ceramic	AA	C929	VCEAGA1AW477M			AB
C723	VCKYCY1HF103Z	J (		Ceramic	AA	C930	VCEAGA1HW476M			AC
C724	VCKYCY1HF103Z	) (		Ceramic	AA	C931	VCEAGA1HW105M			AB
· · · · · · · · · · · · · · · · · · ·	<del> </del>			<del></del>				•	1 50V Electrolytic	AC

Ref. No.	Part No.	*	Descri	ption	Code	Ref. No.	Part No.	*	1	Descripti	ion C	ode
	CAPACITORS	(C	ontinued)				CAPACITORS	(C	ontir	nued)		
C932	VCKYCY1EF104Z	J	0.1 25V	Ceramic	AA	C4403	VCEA2A0JW477M	J	470	6.3V El	lectrolytic	AB
C935	VCKYCY1EF104Z	J	0.1 25V	Ceramic	AA	C4404	VCEAGA1CW476M	J	47	16V EI	lectrolytic	AB
C951	VCKYCY1HF223Z	J	0.022 50V	Ceramic	AA	C5001	VCKYCY1HF103Z	Ţ	0.01	50V C	eramic	AA
C952	VCEAGA1HW335M	J	3.3 50V	Electrolytic	AB	C5002	VCEAGA0JW476M	J	47	6.3V E	lectrolytic	AB
C953	VCEAGA1CW106M	J	10 16V	Electrolytic	AA	C5003	VCKYPA1HF103Z	J	0.01	50V C	eramic	AA
C954	VCEAGA1HW335M	J	3.3 50V	Electrolytic	AB	C5004	VCCCCY1HH470J	j	47p	50V C	eramic	AA
C955	VCEAGA1CW476M	J	47 16V	Electrolytic	AB	C5010	VCKYCY1HF103Z	J	0.01	50V C	eramic	AA
C957	VCEAGA1CW226M			Electrolytic	AB	C5011	VCCCCY1HH470J	J	<b>47</b> p	50V C	eramic	AA
C958	VCEAGA1CW226M								(GM	only)		
C959	VCEAGA1CW476M			Electrolytic		C6601	VCCCCY1HH100D	j	10p	50V C	eramic	AA
C960	VCKYCY1HF103Z	j	0.01 50V	Ceramic	AA				(GM	only)		
C961	VCEAGA1HW105M			Electrolytic	AC	C6602	VCCCCY1HH100D	j	10p	50V C	eramic	AA
C962	VCEAGA1CW476M			Electrolytic					(GM	only)		
C963	VCKYCY1HF333Z	J	0.033 50V	Ceramic	AA	C8851	VCKYCY1HF103Z	J	0.01	50V C	eramic	AA
C965	VCKYPA1HF223Z				AA							
C966	VCEAGA1HW106M			Electrolytic	AC							
C1401	VCFYSA1HB334J			M.Polypro	AB		RESIS	TC	)RS			
C1402	VCFYSA1HB334J			M.Polypro	AB	R201	VRS-CY1JF681J	J	680	1/16W N	/letal Oxide	AA
C1403	VCCCCY1HH820J			Ceramic	AA	R202	VR\$-CY1JF333J	j	33k	1/16W N	/letal Oxide	AA
C1451	VCKYCY1HB102K			Ceramic	AA	R203	VRS-CY1JF103J	J	10k	1/16W N	/letal Oxide	AA
C1452	VCKYCY1HB102K		•		AA	R204	VRS-RA2BE561J	J	560	1/8W C	arbon	AA
C1453	VCEAGA1HW105M			Electrolytic	AC	R205	VRS-CY1JF392J	j	3.9k	1/16W N	/letal Oxide	AA
C1551	VCKYCY1HF103Z			. *	AA	R206	VRS-RA2BE561J	J	560	1/8W C	arbon	AΑ
C1552	VCFYSA1HB104J				ΑB	R207	VRS-RA2BE561J	J	560	1/8W C	arbon	AA
C1553	VCKYPA1HF103Z		1		AA	R208	VRS-RA2BE561J					AA
C1554	VCEAGA1CW106M					R209	VRS-CY1JF152J	J	1.5k	1/16W N	/letal Oxide	AA
C1555	VCKYCY1HF103Z			Ceramic	AA.	R210	VRS-CY1JF222J					
C1557	VCKYCY1HF103Z			Ceramic	AA	R211	VRD-RA2BE271J	J	270	1/8W C	Carbon	AA
C1558	VCKYD41CY103N			Ceramic	AA	R212	VRS-CY1JF472J	J	4.7k	1/16W N	Metal Oxide	AA
C1559	VCEA2A1CW227N					R213	VRS-CY1JF222J	J	2.2k	1/16W N	Vietal Oxide	AA
C1560	VCKYCY1HF1032			Ceramic	AA	R214	VRS-CY1JF103J					
C1801	VCEAGA1HW224N			Electrolytic		R215	VRS-CY1JF222J	J	2.2k	1/16W N	Vietal Oxide	AA :
C1001	*CEAGATITATE III	•	(GM only)			R217	VRS-CY1JF102J					
C1802	VCEAGA1HW104M	1 1		Electrolytic	٠ ΔΔ	R219	VRS-CY1JF122J					
C1602	VCEAGATITATION	. ,	(GM only)	2.000.019	. ,	R220	VRS-CY1JF152J					
C1903	VCEAGA1HW224N			Flectrolytic	- ΔΔ	R226	VRS-CY1JF102J					
Clous	VCEAGATHW224W	, ,	(GM only)	Liectionyti		R228	VRD-RA2BE102					AA
CAROE	VCEAGA0JW476N	<b>a</b> 1		/ Electrolytic	- AR	R229	VRD-RA2BE103.					AA
C1803	VCEAGA01VV470N	. ,	(GM only)	Liectionyth	, AB	R230	VRS-CY1JF103J					
C1006	VCCCPA1HH270			Coramic	AA	R301	VRS-CY1JF681J					
C1000	VCCCFATHH270	, ,	(GM only)	Ceranne	7-0-1	R302	VRS-CY1JF681J					
C1907	VCCCCY1HH220	, ,	•	Ceramic	AA	R303	VRS-CY1JF102J					
C1607	VCCCCTTHH220	, ,	(GM only)	Ceramic	7.7	R304	VRS-CY1JF223J					
C2201	VCEAGA1HW335N	лі	•	Electrolytic	c AR	R305	VRD-RA2BE333.					AA
C2201				Electrolytic		R306	VRS-CY1JF154J					
				•	AA	R307	VRS-CY1JF100J					
C2401				Electrolyti		R330	VRS-CY1JF223J					
C2402				•	AA	R331	VRS-CY1JF473J					
C2403				Ceramic Electrolyti		R332	VRS-CY1JF471J					
C2404				-	AA.	R333	VRS-CY1JF4713					
C2405						R334	VRS-CY1JF561.					
C2406					AA AB	R335	VRS-CY1JF561.					
C2407					AB		VRS-CY1JF862.					
C2408				′ Electrolyti ′ Electrolyti		R336	VRS-CY1JF822.					
C4401				/ Electrolyti		R337	VRS-CY1JF333.					
C4402	VCKYCY1HF103	۷.	: U.U1 50V	Ceramic	AA	R338	V N.3-CT   JP   U.S.		IUK	1/1044	ivietai UXIO	e AA
			<del></del>			_				-		

Ref. No.

Part No.

Description Code Ref. No. Part No. Description Code **RESISTORS (Continued)** RESISTORS (Continued) <sup>∴.</sup>'R703 VRS-CY1JF333J J 33k 1/16W Metal Oxide AA R339 VRS-CY1JF223J J 22k 1/16W Metal Oxide AA R501 VRD-RA2BE102J J 1k 1/8W Carbon ΔΔ R704 VRS-CY1JF222J J 2.2k 1/16W Metal Oxide AA VRS-CY1JF821J J 820 1/16W Metal Oxide AA R502 R705 VRS-CY1JF154J J 150k1/16W Metal Oxide AA R506 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R706 VRS-CY1JF223J J 22k 1/16W Metal Oxide AA R507 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R707 VRS-CY1JF102J J 1k 1/16W Metal Oxide AA VRS-CY1JF122J J 1.2k 1/16W Metal Oxide AA R508 R708 VRD-RA2BE103J J 10k 1/8W Carbon ΔΔ R510 VRS-CY1JF273J J 27k 1/16W Metal Oxide AA R709 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R511 VRS-CY1JF183J J 18k 1/16W Metal Oxide AA R710 VRS-CY1JF102J J 1k 1/16W Metal Oxide AA R513 VRS-CY1JF102J J 1k 1/16W Metal Oxide AA R711 VRD-RA2BE102J J 1k 1/8W Carbon AA R515 VRS-CY1JF102J J 1k 1/16W Metal Oxide AA VRS-CY1JF471J J 470 1/16W Metal Oxide AA R713 R517 VRS-CY1JF102J J 1k 1/16W Metal Oxide AA R714 VRS-CY1JF562J J 5.6k 1/16W Metal Oxide AA R520 VRD-RA2BE102J J 1k 1/8W Carbon VRS-CY1JF682J J 6.8k 1/16W Metal Oxide AA <sup>≙</sup>R715 VRS-CY1JF104J J 100k1/16W Metal Oxide AA R521 R716 VRD-RA2BE393J J 39K 1/8W Carbon ΔΑ **R522** VRD-RA2BE103J J 10k 1/8W Carbon AA R717 VRD-RA2BE183J J 18K 1/8W Carbon AΑ VRD-RA2BE103J J 10k 1/8W Carbon R523 AΑ R718 VRD-RA2BE102J J 1k 1/8W Carbon AΑ R524 VRD-RA2BE103J J 10k 1/8W Carbon AA R719 VRS-CY1JF823J J 82k 1/16W Metal Oxide AA R540 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R720 VRS-CY1JF153J J 15k 1/16W Metal Oxide AA VRS-CY1JF100J J 10 <sup>112</sup>R723 R601 1/16W Metal Oxide AA VRS-CY1JF224J J 220k1/16W Metal Oxide AA VRS-CY1JF333J J 33k 1/16W Metal Oxide AA R602 R724 VRS-CY1JF104J J 100k1/16W Metal Oxide AA R603 VRS-CY1JF221J J 220 1/16W Metal Oxide AA R725 VRS-CY1JF563J J 56k 1/16W Metal Oxide AA R604 VRS-CY1JF274J J 270k1/16W Metal Oxide AA R726 VRS-CY1JF474J J 470k1/16W Metal Oxide AA R605 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R727 VRS-CY1JF272J J 2.7k 1/16W Metal Oxide AA VRS-CY1JF472J J 4.7k 1/16W Metal Oxide AA R606 VRS-CY1JF224J J 220k1/16W Metal Oxide AA R728 VRS-CY1JF332J J 3.3k 1/16W Metal Oxide AA R607 R729 VRS-CY1JF683J J 68k 1/16W Metal Oxide AA R608 VRS-CY1JF822J J 8.2k 1/16W Metal Oxide AA R730 VRS-CY1JF334J J 330k1/16W Metal Oxide AA R609 VRS-CY1JF332J J 3.3k 1/16W Metal Oxide AA R731 VRS-CY1JF392J J 3.9k 1/16W Metal Oxide AA VRS-CY1JF225J J 2.2M1/16W Metal Oxide AA R610 R732 VRS-CY1JF473J J 47k 1/16W Metal Oxide AA R611 VRS-CY1JF563J J 56k 1/16W Metal Oxide AA R733 VRD-RA2BE155J J 1.5M1/8W Carbon AΑ VRS-CY1JF682J J 6.8k 1/16W Metal Oxide AA R612 R734 VRS-CY1JF223J J 22k 1/16W Metal Oxide AA R613 VRD-RA2BE473J J 47k 1/8W Carbon AA R735 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R614 VRS-CY1JF682J J 6.8k 1/16W Metal Oxide AA R736 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA 82k 1/16W Metal Oxide AA R615 VRS-CY1JF823J J R737 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R616 VRS-CY1JF183J J 18k 1/16W Metal Oxide AA R738 VRD-RA2BE223J J 22k 1/8W Carbon AA R617 VRS-CY1JF152J J 1.5k 1/16W Metal Oxide AA R739 VRS-CY1JF153J J 15k 1/16W Metal Oxide AA R618 VRD-RA2BE153J J 15k 1/8W Carbon AΑ R741 VRS-CY1JF104J J 100k1/16W Metal Oxide AA VRS-CY1JF101J J R619 100 1/16W Metal Oxide AA VRS-CY1JF273J J 27k 1/16W Metal Oxide AA R742 VRS-CY1JF471J J 470 1/16W Metal Oxide AA R620 R743 VRS-CY1JF334J J 330k1/16W Metal Oxide AA VRD-RA2BE683J J 68k 1/8W Carbon R621 R744 VRD-RA2HD1R0J J 1 1/2W Carbon AΑ R622 VRS-CY1JF683J J 68k 1/16W Metal Oxide AA R745 VRD-RA2HD1R0J J 1 1/2W Carbon AΑ R623 VRS-CY1JF333J J 33k 1/16W Metal Oxide AA R746 VRD-RA2BE102J J 1k 1/8W Carbon AΑ VRS-CY1JF563J J 56k 1/16W Metal Oxide AA R624 R747 VRD-RA2BE103J J 10k 1/8W Carbon AΑ R625 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R748 VRS-CY1JF223J J 22k 1/16W Metal Oxide AA VRS-CY1JF332J J 3.3k 1/16W Metal Oxide AA R626 VRD-RA2BE471J J 470 1/8W Carbon R752 AA R629 VRS-CY1JF153J J 15k 1/16W Metal Oxide AA R801 VRD-RA2BE102J J 1k 1/8W Carbon AΑ VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R630 R802 VRD-RA2BE102J J 1k 1/8W Carbon AΑ 1/16W Metal Oxide AA R631 VRS-CY1JF470J J 47 R804 VRD-RA2BE471J J 470 1/8W Carbon AΑ R632 VRS-CY1JF682J J 6.8k 1/16W Metal Oxide AA R805 VRD-RA2BE471J J 470 1/8W Carbon AΑ VRG-SC2EB4R7J J 4.7 1/4W Fuse Resistor AB R633 VRS-CY1JF471J J 470 1/16W Metal Oxide AA R806 R634 See Control R807 VRS-CY1JF471J J 470 1/16W Metal Oxide AA R635 VRS-CY1JF153J J 15k 1/16W Metal Oxide AA VRS-CY1JF102J J 1k R809 1/16W Metal Oxide AA R636 VRS-CY1JF562J J 5.6k 1/16W Metal Oxide AA R810 VRS-CY1JF102J J 1k 1/16W Metal Oxide AA 6.8k 1/16W Metal Oxide AA R637 VRS-CY1JF682J J VRS-CY1JF471J J 470 1/16W Metal Oxide AA R812 R638 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA R813 VRS-CY1JF103J J 10k 1/16W Metal Oxide AA VRD-RA2BE153J J 15k 1/8W Carbon R639 R814 VRD-RA2BE102J J 1k 1/8W Carbon AA R701 VRS-CY1JF272J J 2.7k 1/16W Metal Oxide AA R815 VRS-CY1JF104J J 100k1/16W Metal Oxide AA

Ref. No.	Part No.	Descri	ption C	ode	Ref. No.	Part No.	*	Description	Code
<del></del>	RESISTORS (C	ontinued)				RESISTORS	(Co	ontinued)	
R821	VRS-CY1JF472J J	4.7k 1/16W	Metal Oxide	AA	R970	VRS-CY1JF333J	J	33k 1/16W Metal Oxid	le AA
R822	VRS-CY1JF273J J	27k 1/16W	Metal Oxide	AA	R971	VRD-RA2HD471J	j	470 1/2W Carbon	AA
R823	VRD-RA2BE471J J	470 1/8W	Carbon	AA	R1401	VRS-CY1JF103J	J	10k 1/16W Metal Oxid	e AA
R824	VRD-RA2BE103J J	10k 1/8W	Carbon	AA	R1402	VRS-CY1JF103J	J	10k 1/16W Metal Oxid	e AA
R825	VRD-RA2BE103J J	10k 1/8W	Carbon	AA	R1403	VRS-CY1JF103J	J	10k 1/16W Metal Oxid	ie AA
R851	VRD-RA2EE151J	150 1/4W	Carbon	AA	R1404	VRS-CY1JF153J	J	15k 1/16W Metal Oxio	le AA
R854	VRS-CY1JF123J J	12k 1/16W	Metal Oxide	AA	R1405	VRS-CY1JF183J	J	18k 1/16W Metal Oxid	le AA
R855	VRD-RA2BE123J J	12K 1/8W	Carbon	AA	R1406	VRS-CY1JF103J	J	10k 1/16W Metal Oxid	le AA
R856	VRD-RA2BE103J J	10k 1/8W	Carbon	AA	R1451	VRS-CY1JF561J	J	560 1/16W Metal Oxid	le AA
R857	VRD-RA2BE271J J	270 1/8W	Carbon	AA	R1452	VRS-CY1JF561J	J	560 1/16W Metal Oxid	le AA
R858	VRS-CY1JF104J J	100k1/16W	Metal Oxide	AA	R1453	VRD-RA2EE472J	J	4.7k 1/4W Carbon	AA
R859	VRD-RA2BE271J J	270 1/8W	Carbon	AA	R1555	VRS-CY1JF334J	J	330k 1/16W Metal Oxid	le AA
R860	VRS-CY1JF104J J	100k 1/16W	/ Metal Oxide	AA	R1556	VRS-CY1JF474J	J	470k 1/16W Metal Oxio	le AA
R861	VRD-RA2BE221J J	220 1/8W	Carbon	AA	R1557	VRS-CY1JF101J	J	100 1/16W Metal Oxid	le AA
R862	VRD-RA2BE154J J	150k1/8W	Carbon	AA	R1801	VRS-CY1JF331J	J	330 1/16W Metal Oxid	le AA
R863	VRD-RA2BE221J	220 1/8W	Carbon	AA				(GM only)	
R864	VRS-CY1JF154J	150k1/16W	/ Metal Oxide	AA	R1802	VRS-CY1JF331J	J	330 1/16W Metal Oxid	le AA
<u> </u>	VRD-RA2HD105J	1M 1/2W	Carbon	AA				(GM only)	
<u></u> <b>₹</b> R902	VRC-UA2HG685K	6.8M1/2W	Solid	AA	R1803	VRS-CY1JF331J	J	330 1/16W Metal Oxid	le AA
<u>∧</u> R903	VRC-UA2HG685K	6.8M1/2W	Solid	AA				(GM only)	
<u></u> R904	RR-WZ0003GEZZ J	4.7 2W	Cement	AD	R1804	VRS-CY1JF472J	J	4.7k 1/16W Metal Oxid	le AA
<u> </u>	VRD-RA2HD224J J	220k1/2W	Carbon	AA				(GM only)	
<u>∧</u> R906	VRD-RA2HD224J J	220k1/2W	Carbon	AA	R1805	VRS-CY1JF223J	J	22k 1/16W Metal Oxid	ie AA
<u> </u>	VRD-RAZEE563J	56k 1/4W	Carbon	AA				(GM only)	
<u> </u>	RR-SZ0007GEZZ	68k 2W	Cement	AB	R1806	VRS-CY1JF223J	J	22k 1/16W Metal Oxid	le AA
<u></u> ₹909	VRD-RA2HD470J		Carbon	AA				(GM only)	
<u> </u>	VRD-RA2HD470J .		Carbon	AA	R2201	VRS-CY1JF750J	J	75 1/16W Metal Oxid	le AA
<u></u> <b>₹</b> R911	VRD-RA2EE471J .		Carbon	AA	R2202			100 1/16W Metal Oxid	le AA
R921	VRG-SC2EB1R0J .	1 1/4W	Fuse Resistor	AB	R2203			390 1/8W Carbon	AA
R922	VRD-RA2HD100J .		Carbon	AA	R2401		_	3.9k 1/16W Metal Oxid	
R924	VRG-SC2EB100J .		Fuse Resistor		R2402			680 1/16W Metal Oxid	AA ek
R925	VRD-RA2BE221J .			AA	R2403			150k1/8W Carbon	AA
R926	VRS-CY1JF221J .				R2404			1k 1/8W Carbon	AA
R <b>927</b>	VRS-CY1JF272J				R2405			1k 1/8W Carbon	AA
R928	VRS-CY1JF103J				_	VRD-RA2BE684			AA
R929	VRS-CY1JF183J				R4401	VRD-RA2BE181.	J	180 1/8W Carbon	AA
R930	VRS-CY1JF392J				R4402			150 1/8W Carbon	AA
R931	VRS-CY1JF682J				R4403			75 1/8W Carbon	AA
R932	VRS-CY1JF221J				R4404			100k 1/16W Metal Oxid	
R933	VRS-CY1JF222J				R4405			100 1/16W Metal Oxid	
R951	VRD-RA2BER56J			AA	R4407			3.3k 1/16W Metal Oxid	
R952	VRD-RA2BER56J			AA	R5001			470 1/16W Metal Oxid	
R953	VRD-RA2HD472J			AA	R5002	VRD-RAZEE1RO			AA
R954	VRD-RA2BE270J			AA	R5003			100k1/8W Carbon	AA
R955	VRD-RAZBE683J			AA	R5004			100k1/16W Metal Oxid	-
R956	VRS-CY1JF103J				R5005			100k1/16W Metal Oxid	
R960	VRS-CY1JF472J				R5006			100k1/16W Metal Oxid	
R961	VRD-RA2BE562J			AA	R5007			100k1/16W Metal Oxid	
R962	VRS-CY1JF683J				R6601			10k 1/16W Metal Oxid	
R963	VRS-CY1JF472J				R6602			10k 1/16W Metal Oxid	-
R964	VRD-RA2BE102J			AA	R6609			2.7k 1/16W Metal Oxid	
R965	VRS-CY1JF123J				R6610			6.8k 1/16W Metal Oxid	
R966	VRD-RA2BE681J			AA				330 1/16W Metal Oxid	
R967	VRD-RA2BE333J			AA				3.3k 1/16W Metal Oxid	
R969	VRD-RA2HD561J	J 50U 1/2W	Carbon	AA	K8851	v K5-CY1JF472.	J	4.7k 1/16W Metal Oxid	AA 9t
								·	

Ref. No. Part No. Description Code Ref. No. Part No. Code Description RESISTORS (Continued) **DUNTK4929TEV2** R8852 VRS-CY1JF223J J 22k 1/16W Metal Oxide AA **OPERATION UNIT** 17831 MISCELLANEOUS PARTS **MISCELLANEOUS PARTS** SC8801 QSOCZ0657GEZZ J Socket 6pin (OA) A DG5001 VVK10BT143G-1 J Fluorescent Display Tube AT AB QSW-K0079GEZZ J Switch, Stop/Eject S8801 **№** F901 QFS-C2026CEZZ J Fuse T2AH/250V AB \$8802 Q\$W+K0079GEZZ J Switch, Play RBLN-0013GEZZ J Férrité Bead ΑB ΑB \$8803 QSW-K0079GEZZ J Switch, REC 6. FB2201 RBLN-0043CEZZ J Ferrite Bead (GM only) AB AB S8804 QSW-K0079GEZZ J Switch, Pause/Still AFH901 QFSHD1009CEZZ J Fuse Holder AB ∍ AA QSW-K0079GEZZ J Switch, CH (+) ♠ FH902 QFSHD1010CEZZ J Fuse Holder AB AA S8806 QSW-K0079GEZZ J Switch, CH (-) ΑB P601 م QPLGN0247REZZ J Plug, 2pin (AE) AΑ S8807 QSW-K0079GEZZ J Switch, REW ...P701 QPLGN0657REZZ J Plug, 6pin (AO) AB : AC QSW-K0079GEZZ J Switch, FF AB . P702. QPLGN0247REZZ J Plug, 2pin (AL) AA P704 QPLGZ1074GEZZ J Plug, 10pin (AC) AC P705 QPLGZ0360GEZZ J Plug, 3pin (AR) ΔΔ QPLGN0269GEZZ J Plug, 2pin (PA) AΒ - SC301 QSOCN0794REZZ J Socket, 7pin (AH) ΑE SC601 QSOCN0884REZZ J Socket, 8pin (AA) AB SC701 QSOCN0684REZZ J Socket, 6pin (AD) ΑB SC2201 QSOCZ1280GEZZ J Socket, A/V ΔH S851 QSW-K0042AJZZ V Switch, Rec AC S5001 OSW-K0002AJZZ V Switch, Power AD S5002 QSW-K0002AJZZ V Switch, TV/VCR ΑD End of Operation -QSW-K0002AJZZ V Switch, Set-up AD Ref. No. Part No. Description Code DUNTK4930TEV1 R/C RECEIVER UNIT MISCELLANEOUS PARTS SC5501 QSOCZ0360GEZZ J Socket 3pin (RA) ΑB RMC5501 RRMCU0209CEZZ J Remote Control Receiver AH End of Main

- End of R/C Receiver -

Ref. No.	Part No.	*	Description	Code	Ref. No.	Part No.	*	Description	Code
	IECHANISM C	<u>`</u> H.	ASSIS PARTS	_ <del></del>	45	MLEVF0422AJZZ	٧	Supply Loading Arm Ass'y	AG
17	IFCI IVIAI 2141		AJJIJ I AKTI		46	CLEVP0239AJ00	٧	Auto Head Cleaner Ass'	y AF
4	LCHSM0148AJZZ	· · ·	Main Charris Acc'y	AY	47	MSPRT0379AJFJ	٧	Loading Double Action	AB
1			Supply Impedance Rolle					Spring	
2	PGIDH0031AJFW			AD	48	NDAiV1065AJ00	٧	Reel Disk	ΑB
3	PGIDHUUSIAJEW	٧	Roller Frange	70	49	MARMP0053AJZZ	٧	Reel Idler	AM
4	PGIDS0027AJZZ	v	_	AA	50	MLEVP0240AJZZ	٧	Clutch Lever	AB
4	PG1D3002/AJ22	٧	Roller Lower Frange	7	51	NGERH1221AJZZ	٧	Clutch Gear Ass'y	AK
5	NSFTL0563AJFW	v	_	ΑE	52	NPLYV0147AJZZ	٧	Reel Pulley Ass'y	AP
3	Mat I Forday Mill	•	Roller Inner		53	NGERH1224AJZZ		•	AD
6	LPO1M0050GE77	, ,	Supply Pole Base Ass'y	AM	54			Clutch Connect Arm	AB
7			Take-Up Pole Base Ass'y		55	MLEVP0242AJZZ	٧	Take-Up Main Brake	AK
8	NROLP0110GEZZ			AH				Ass'y	
9			Reverse Guide Lever Ass		56			Take-Up Lock Lever	AC
10			Reverse Guide Spring	AB	57	MLEVP0244AJZZ	٧	Supply Main Brake	AH
11			Reverse Guide Spacer	AE				Lever Ass'y	
12			Audio/Control Head	AR	58	MSPRT0380AJFJ	٧	Main Brake Spring	AB
			Audio/Control Head Arr		59	NGERH1225AJZZ	٧	Cassette Hausing	AD
13			Audio/Control Head	AB				Control Drive Gear	
14	MISEKDOLAOMIEI	V		AD	60	PREFL1004AJZZ	٧	Light Guide	AD
		,	Arm Spring	АВ	61	MLEVP0250AJZZ	٧	Slow Brake Ass'y	ĄD
15	MSPRC0189AJF.			AK	62	MSPRT0383AJFJ	V	Slow Brake Spring	АÇ
16	RHEDT0032GEZZ			AB	63	RMOTN2051GEZZ	۱.	Capstan Motor	BD
17	PSPAZU39ZAJZZ	. v	Audio/Control Head	Ab	64	RMOTM1062GEZZ	J	Loading Motor	AP
			Arm Spacer	ID & C	65	QCNW-0156AJZZ	. v	Lead Wire for Loading	ΑE
18			Audio/Control Head PW					Motor	•
19	QSOCN0885REZ			AB	66	QCNW-0155AJZZ	. v	FFC for Audio/Control	AF
20	NBLTK0065AJ00			AE	67	QCNW-0157AJZZ			AF
21			Pinch Roller Lever Ass'y		68	PSPAZ0434GEFW			AL
22	MLEVP0237AJZZ	. v	Pinch Double Action	AD	69	LX-XZ3032GEFP	J	Preload Collar	AC
			Lever			4		Mounting Set Screw	
23			Pinch Drive Lever Ass'y	AG	*.			(M4 + 5WP)	
24	NGERH1216AJZ			AE	70	PGIDC0052GEFW	/ ]	Drum Base	AK
25	MLEVP0238AJZZ		•	AC	71	XBPSD30P08J00	J	Drum Base Mounting	AA
26	MSPRT0377AJF	ΙV	Pinch Double Action	AC				Screw (SW3P + 8S)	
			Spring		72	OBRSK0034GEZZ	. J		AD
27	MSPRD0149AJF.			AB	73	MSPRC0194GEF			AA
28	MLEVF0418AJZ			AG	,,,		-	Spring	
29	LBOSZ1001AJZ			AB	74	RMOTP1116GEZZ	<u>'</u> ]		BF
30	MSPRT0378AJF		. •	AC	75	XBPSD26P06J00			AΑ
31			Tension Band Ass'y	AG	,,	X2, 2220. 0010.		Mounting Screw	
32			Tension Pole Adjust Ca					(SW2.6P + 6S)	
33	NGERH1217AJ0			ΑE	76	DDRMW0015TEV	nι		BS
34	NPLYV0146AJZ		•	AB	,,	DD (((((()))))		. 2.0	
35	NGERW1051AJZ			AC					
36			Worm Wheel Gear	AC					
37	NGERH1218AJZ			AC					
38	LANGK0161AJZ	ΖV	Loading Motor Angle Ass'y	AD					
39	NBRGP0017AJZ	z v	Bearing	AB					
40	MSLiP0006AJZ	z v	Sifter	AH					
41			Sifter Drive Lever Ass'y	AG					
42			Take-Up Loading Gear						
43			Take-Up Loading Arm Ass'y	AG					
44	NGERH1220A17	zν	Supply Loading Gear	AC		End of Med	ha	nism Chassis Parts -	
77	110211112201112	_	cappiy according according						

Ref. No. Part No. ★ Description ©Code Ref. No. © Part No. ★ Description ©Code

## CASSETTE HOUSING CONTROL PARTS

#### **SCREWS, NUTS AND WASHERS**

CASS	ETTE HOUSING C	ON I ROL PAR	(15 **	SC	ND WASHERS			
300	CHLDX3070TEV1 U Ca	assette Housing	AX	200	LX-XZ3030GEFD	J	Set Screw	AC
301	Co LHLDX1024AJ00 V Fr	ontrol Ass'y	AG	201	ELX-BZ3095GEFD	j		ÁΑ
302	LHLDX1025AJ00 V Fr	• •	ÁG	202	LV BZŽAGCČEED		Screw	
303	NGERR3003AJFW V Dr	* *	AE	202	LX-BZ3096GEFD		Tilt Adjusting Screw	AA
304	NGERR1005AJZZ V Do	-	AC	203	XBPSD26P06000	J	Azimuth Adjusting	AA
305	MSPRT0381AJFJ V Do		AC	204	VIIDEDZEDOOMEO		Screw (2.6P + 6S)	
306	MSLIF0070AJFW V SII		AH	204	XHPSD26P08WS0	J.		AA
307	LHLDX1026AJ00 V Ho		AD	206	XBPSD30P04J00		(For FE Head)	
308	MLEVP0246AJ00 V Pr		AB		- <b>жығарабру4100</b> Авг	J	Screw, SW3P + 4S	AA
309	MSPRD0150AJFJ V Pro		AB	207	XHPSD26P06000		(For Loading Motor)	
310	LHLDX1027AJ00 V Ho		AD	1.	-2	J	Screw, 2.6P + 6\$	ÅΑ
311	MSPRP0159AJFJ V Ca		AD	208	XHPSD26P06WS0		(For Capstan Motor)	
312	MLEVF0424AJFW V Pro		AC	200		,	Screw, C2.6P + 6S	AA
313	MSPRD0151AJFJ V Pro		AB				(For Loading Motor Angle Ass'y)	
314	NGERH1226AJ00 V Dr		AD	209	≥XHPSD30P08WS0		Screw, C3P + 8\$	
315	MSPRD0152AJFJ V Dr		AC	5. <b>203</b> 7.1	25477 30301 0 <b>0473</b> 0	,	(For Drum Base)	AA
<sup>ਂ</sup> 316	NGERH1227AJ00 V Dr		AD	210	LX-NZ3046GEFW		X-Position Adjusting	A D
317	MSPRD0153AJFJ V Dr		AC		2X 1123040GE1 ##	,	Nut	AB
318	NGERH1228AJ00 V Sy		AC	-211	LX-NZ3019GEZZ	ŧ	Reverse Guide	SA D
319		ain Shaft	AG		2X 1123013GEZZ	•	Adjusting Nut	AB
320		per Plate	AH	212	XNFSD40-31000	1	Audio/Control Head	AB
321	•	or Open Lever	AC	212	XIII 3D 40-31000	,		AB
322	MLEVP0248AJ00 V Sei	•	AB	213	XNFSD20-16000		Adjusting Nut (M4)	* *
323	MSPRT0382AJFJ V Se		AB		VML2D50-10000	J	S.I. Roller Adjusting	ÁΑ
324		P + 6S	AA	214	YWU1762 05110		Nut (M2) Washer, W5.2P-11-0.5	
	and the second s	or Cassette Housing	~~	214	XWHJZ32-05110	J		AB
		ntrol)		215	YWU 1752-02110	.,	(Reel Height Adj.) Washer, W5.2P-11-0.3	
325	PSPAHOOO8AJOO V Spa		AB	213	A WIII 2 2 2 - 0 3 1 1 0	٧		AB
				216	YWH1752-04110	v	(Reel Height Adj.) Washer, W5.2P-11-0.4	
				210	XWHJ252-04110	٧		AB
				217	XWH1752-06110	v	(Reel Height Adj.) Washer, W5.2P-11-0.6	Á.D.
				218			Washer, W5.2P-11-0.7	AB
				219				AB
				- 220	LX-WZ1073GE00		Washer, W3.1P-7-0.25	AA
				220	LX-W21073GE00	,		AB
				221	LV W710066500		CW4.5P-11-0.5	
				221	LX-WZ1006GE00	J	CW2.6P-5,4-0.5	AA
				222	LX-WZ1041GE00	í	· -	4.4
					EX-10-10-00	,	CW2.6P-6-0.5	AA
				223	XRESJ40-06000	1		* *
				224	LX-WZ1077AJ00			AA
					EX-WE1077AJ00	٧	Washer to.4	AB
							(Worm Gear THRUST	
							PLAY Adj.)	
				225	LX-WZ1078AJ00	v		4 D
					WE (0/0A)00	٠	Washer to 5	AB
							(Worm Gear THRUST	
				r			PLAY Adj.)	Table
				226	LX-WZ1079AJ00	ν		
					11	•	Washer to.6	ÅΒ
							(Worm Gear THRUST	
	<b>End of Cassette Housing</b>	Control Parts					PLAY Adj.)	
							· Mi Auj.)	•

Code Ref. No. Part No. Ref. No. Part No. Description Description Code SCREWS, NUTS AND WASHERS FRONT PANEL PARTS (Continued) LX-WZ1080AJ00 V Bearing Fixed ΑB 501 CPNLC1870TEV0 U Front Panel Ass'v 227 BA Washer t0.7 (VC-A462GM) (Worm Gear THRUST 501 CPNLC1878TEV0 U Front Panel Ass'y BΑ PLAY Adj.) (VC-A462SM) LX-WZ1081AJ00 V Bearing Fixed JBTN-2608UMSA U Operate Button 228 ΑB AC 501-3 Washer t0.8 CBTN-2597TEV3 U Play Button Ass'y ΑK (Worm Gear THRUST 501-3-1 JBTN-2597UMSC U Play Button ΑF 501-3-2 JBTN-2598UMSC U FF/REW Button PLAY Adj.) ΑF 501-4 JBTN-2609UMSA U CH Set Button AC 501-5 HDECQ1185UMSA U Front Decoration ΑG Window 501-6 HDECQ1207UMSB U Cassette Flap AG End of Screws, Nuts and Washers 501-7 HBDGB1008AJSA V Badge, "SHARP" AΕ 501-8 MSPRD0103AJFJ V Cassette Spring AΒ MECHANICAL PARTS ΑU GCABA3090UMSE U Top Cabinet 601 CCABB1143TEV0 U Frame Ass'v ΑV 602 AB PFLT-0016AJZZ V FootFelt 602-2 GCOVA1841UMZZ U Antenna Terminal Cover AE 603 604 LX-HZ3079GEFD U Screw AB XEBSD30P12000 J Screw AΑ 605 XEBSD40P12000 J Screw AA 606 AΑ XHPSD30P06WS0 J Screw 607 XESSF30P12000 J Screw AΑ 608 AC 609 PSPAZ0390AJZZ V Spacer 610 PSLDM4449UMFW U Head Amp. Shield (Top) AB P\$LDM4450UMFW U Head Amp. Shield AB 611 (Bottom) LANGQ9054UMFW U Trans Earth Angle AC 612 PSPAZ0456UMZZ U Spacer AΑ 613 LHLDZ1909UMZZ U Tuner Holder AB 614 LANGQ9055UMFW U Conv. Earth Angle AC 615 AΑ 616 LX-HZ3030GEFF J Screw ΑD PSLDM4469UMFW U FFCShield 617 618 LHLDP1143UMZZ U LEDHolder ΑD AC 619 TLABM0132UMZZ U Model Label (VC-A462GM) ΑD 619 TLABM0133UMZZ U Model Label (VC-A462SM) 620 PSPAZ0453AJZZ V Spacer AC LHLDZ1746UMZZ U Converter Holder 621 ΑE GBDYU3089UMZZ U Bottom Plate AG 622

End of Front Panel Parts -

**End of Mechanical Parts -**

...

17.

Ref. No.

Part No.

Description

Co

ಾ ಚಿತ

របស់ផ្ទៅស្វេនស..

wolfigen.

newal gura

突性實驗的 医多种动物

Thirty Company pour

SUPPLIED: ACCESSORIES

VILLET BURGESSORIES, TRIDLINGO \* ACC901 QACCV2001AJZZ V ACCord ÄQ QCNW-7544UMZZ U 75.ohm Coaxial Cable . AL 41.10 RRMCG0009AJSA V Infrared Remote Control AX GROUP ARUNITADO A COMO DE COMO 93GHR14172001 VyBattery-Covery 10 Hereing Delnfrared-R/C, Unity Figure 4.6 PROPERTY DESPRESSION FORESTONE HARLES (LEH) HE ARMORDE GAS-KTAL ACCESSORIES (NOT REPLACEMENT ITEM) ٥., TiNS-2343UMZZ - Operation Manual (VC-A462GM)

— End of Supplied Accessories —

TINS-2368UMZZ - Operation Manual

501-8 AFC (M**8594A625M)** 5 FO FO BERTON

\* Remark: VC-A4625M

When changing main cord the whole cord with connection plug must be changed.

The cable is kept as a spare part by:

- SWEEDEN
  - SHARP ELECTRONICS (SVENSKA) AB
- DENMARK

**RUDOLPH SCHMIDT A/S** 

• FINLAND

ASA KULUTUS ELEKTRONIIKA OY

NORWAY

TRANSEL A/S

\* Bemerkung: VC-A462SM

Bei der Auswechselung des Netzkabels muß das ganze Kabel mit Stecker ausgewechselt werden.

The sections

Hat das Kabel als Ersatzteil vorrätig:


- SCHWEDEN
  - SHARP ELECTRONICS (SVENSKA) AB
- DÄNEMARK


**RUDOLPH SCHMIDT A/S** 


- FINNLAND
  - ASA KULUTUS ELEKTRONIIKA OY
- NORWEGEN


TRANSEL A/S

SCREWED DUNG A VENANGERS











#### PRECAUTIONS ON FRONT PANEL SET-UP




Before attaching the front panel in position, make sure that the cassette cover open lever is in its right place (lower-most). If it is out of position, push it down with a finger.



Keep the cassette over about 45° open and make sure that the cassette cover open lever is between the front panel and the cas-sette cover. Now fix the front panel in place.

Do not mount the front panel with the cassette cover tilted too open. Otherwise the cassette cover might wrongly run on the cassette housing.




Removing the cassette compartment

- Open the cassette compartment cover fully.
   Remove the center positioner.
- Slide the cover to the right.
  Slightly bend the cover.
  Draw out the left-side rod.

# 12. PACKING OF THE SET

## Setting position of the Knobs

RF Converter Adjuster	at "E36" position	Test Signal Switch	at "OFF" position



VC-A462GM VC-A462SM

# SHARP